

# Rosemount™ 3051S MultiVariable™ Transmitter



## Safety messages

### **⚠ WARNING**

Read this manual before working with the product. For personal and system safety, and for optimum product performance, ensure the contents are thoroughly understood before installing, using, or maintaining this product.

### **⚠ WARNING**

Explosions could result in death or serious injury.

Installation of this transmitter in an explosive environment must be in accordance with the appropriate local, national, and international standards, codes, and practices. Review the approvals section of the Quick Start Guide for any restrictions associated with a safe installation.

Before connecting a handheld communicator in an explosive atmosphere, ensure that the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.

In an explosion-proof/flameproof installation, do not remove the transmitter covers when power is applied to the transmitter.

### **⚠ WARNING**

Process leaks could result in death or serious injury.

Install and tighten process connectors before applying pressure.

Do not attempt to loosen or remove flange bolts while the transmitter is in service.

### **⚠ WARNING**

Electrical shock can result in death or serious injury. High voltage that may be present on leads could cause electrical shock.

Avoid contact with the leads and terminals.

### **⚠ WARNING**

Replacement equipment or spare parts not approved by Emerson for use as spare parts could reduce the pressure retaining capabilities of the transmitter and may render the instrument dangerous.

Use only bolts supplied or sold by Emerson as spare parts.

### **⚠ WARNING**

#### **Physical access**

Unauthorized personnel may potentially cause significant damage to and/or misconfiguration of end users' equipment. This could be intentional or unintentional and needs to be protected against.

Physical security is an important part of any security program and fundamental in protecting your system. Restrict physical access by unauthorized personnel to protect end users' assets. This is true for all systems used within the facility.

### **NOTICE**

The products described in this document are NOT designed for nuclear-qualified applications. Using non-nuclear qualified products in applications that require nuclear-qualified hardware or products may cause inaccurate readings. For information on Emerson nuclear-qualified products, contact your local Emerson Sales Representative.

## NOTICE

Improper assembly of manifolds to traditional flange can damage sensor module.

For safe assembly of manifold to traditional flange, bolts must break back plane of flange web (also called bolt hole) but must not contact sensor module housing.

---



# Contents

|                  |   |            |
|------------------|---|------------|
| <b>Chapter 1</b> | <b>Introduction.....</b>  | <b>7</b>   |
|                  | 1.1 Models covered.....   | 7          |
|                  | 1.2 Product recycling/disposal.....                                     | 7          |
| <b>Chapter 2</b> | <b>Configuration.....</b>   | <b>9</b>   |
|                  | 2.1 Overview.....   | 9          |
|                  | 2.2 Engineering Assistant installation.....                             | 9          |
|                  | 2.3 Configuring flow.....   | 11         |
|                  | 2.4 Basic device configuration.....                                     | 29         |
|                  | 2.5 Detailed device configuration .....                                 | 31         |
|                  | 2.6 Variable configuration .....  | 40         |
|                  | 2.7 Menu trees and communication device fast keys.....                  | 59         |
| <b>Chapter 3</b> | <b>Installation.....</b>  | <b>69</b>  |
|                  | 3.1 Overview.....   | 69         |
|                  | 3.2 Installation considerations.....                                    | 69         |
|                  | 3.3 Installation procedures.....  | 70         |
|                  | 3.4 Rosemount 305 and 304 Manifolds.....                                | 92         |
| <b>Chapter 4</b> | <b>Operation and maintenance.....</b>                                   | <b>103</b> |
|                  | 4.1 Overview.....   | 103        |
|                  | 4.2 Transmitter calibration.....  | 103        |
|                  | 4.3 Transmitter functional tests.....                                   | 111        |
|                  | 4.4 Process variables.....  | 112        |
|                  | 4.5 Field upgrades and replacements.....                                | 114        |
| <b>Chapter 5</b> | <b>Troubleshooting.....</b>   | <b>121</b> |
|                  | 5.1 Overview.....   | 121        |
|                  | 5.2 Device diagnostics.....   | 121        |
|                  | 5.3 Measurement quality and limit status.....                           | 131        |
|                  | 5.4 Engineering Assistant communication.....                            | 132        |
|                  | 5.5 Measurement troubleshooting.....                                    | 133        |
| <b>Chapter 6</b> | <b>Safety Instrumented Systems (SIS) requirements.....</b>              | <b>139</b> |
|                  | 6.1 Safety Instrumented Systems (SIS) certification.....                | 139        |
|                  | 6.2 Safety certified identification.....                                | 139        |
|                  | 6.3 Installation in Safety Instrumented Systems (SIS) applications..... | 139        |
|                  | 6.4 Configuring in Safety Instrumented Systems (SIS) applications.....  | 140        |
|                  | 6.5 Safety Instrumented Systems (SIS) operation and maintenance.....    | 141        |
|                  | 6.6 Inspection.....   | 143        |
| <b>Chapter 7</b> | <b>Reference data.....</b>  | <b>145</b> |
|                  | 7.1 Product certifications.....   | 145        |
|                  | 7.2 Ordering Information, Specifications, and Dimensional Drawings..... | 145        |



# 1 Introduction

## 1.1 Models covered

The following transmitters are covered in this manual:

**Table 1-1: Rosemount 3051SMV Measurement with Fully Compensated Mass and Energy Flow Output**

| Measurement type | MultiVariable type: M                               |
|------------------|---|
| 1                | Differential pressure, static pressure, temperature |
| 2                | Differential pressure and static pressure           |
| 3                | Differential pressure and temperature               |
| 4                | Differential pressure                               |

**Table 1-2: Rosemount 3051SMV Measurement with Direct Process Variable Output**

| Measurement type | MultiVariable type: P                               |
|------------------|---|
| 1                | Differential pressure, static pressure, temperature |
| 2                | Differential pressure and static pressure           |
| 3                | Differential pressure and temperature               |
| 5                | Coplanar™ static pressure and temperature           |
| 6                | In-line static pressure and temperature             |

## 1.2 Product recycling/disposal

Consider recycling equipment and packaging.

Dispose of the product and packaging in accordance with local and national legislation.





## 2 Configuration

### 2.1 Overview

This section contains information for configuring the transmitter.

[Engineering Assistant installation](#) and [Configuring flow](#) instructions apply to Engineering Assistant version 6.3 or later. [Basic device configuration](#), [Detailed device configuration](#), and [Variable configuration](#) apply to AMS Device Manager version 9.0 or later, but also include fast key sequences for communication device version 2.0 or later. Engineering Assistant and AMS Device Manager screens are similar and follow the same instructions for use and navigation. For convenience, fast key sequences are labeled *Fast keys* for each software function below the appropriate headings. [Table 2-1](#) shows the functionality of each host.

#### Note

Coplanar™ transmitter configurations measuring gauge pressure and process temperature (measurement 5) will report as the pressure as differential pressure. This will be reflected on the LCD display, nameplate, digital interfaces, and other user interfaces.

**Table 2-1: Host functionality**

• Available

— Not available

| MultiVariable type                         | Functionality        | Engineering Assistant | AMS Device Manager | Communication device |
|--|----------------------|-----------------------|--------------------|----------------------|
| Fully compensated mass and energy flow (M) | Flow Configuration   | •                     | •                  | —                    |
|  | Device Configuration | •                     | •                  | •                    |
|  | Test Calculation     | •                     | •                  | •                    |
|  | Calibration          | •                     | •                  | •                    |
|  | Diagnostics          | •                     | •                  | •                    |
| Direct process variable output (P)         | Device Configuration | —                     | •                  | •                    |
|  | Calibration          | —                     | •                  | •                    |
|  | Diagnostics          | —                     | •                  | •                    |

### 2.2 Engineering Assistant installation

#### 2.2.1 Engineering Assistant version 6.3 or later

The Rosemount 3051SMV Engineering Assistant 6.3 or later is personal computer (PC)-based software that performs configuration, maintenance, and diagnostic functions and serves as the primary communication interface to the 3051SMV with the fully compensated mass and energy flow feature board.

The 3051SMV Engineering Assistant software is required to complete the flow configuration.

## 2.2.2 Installation and initial setup

The following are the minimum system requirements to install the Engineering Assistant software:

- Pentium-grade Processor: 500 MHz or faster
- Operating system: Windows® Professional 7, 8.1, 10
  - 32-bit
  - 64-bit
- 256 MB RAM
- 100 MB free hard disk space
- RS232 serial port or USB port (for use with HART® modem)
- CD-ROM

### Installing the 3051SMV Engineering Assistant version 6.3 or later

Engineering Assistant is available with or without the HART® modem and connecting cables.

The complete Engineering Assistant package contains the software CD and one HART modem with cables for connecting the computer to the Rosemount 3051SMV.

#### Procedure

1. Uninstall any existing versions of Engineering Assistant 6 currently installed on the PC.
2. Insert the new Engineering Assistant disk into the CD-ROM. Windows® should detect the presence of a CD and start the installation program. Follow the on-screen prompts to finish the installation.
3. If Windows does not detect the CD, use Windows Explorer or My Computer to view the contents of the CD-ROM, and then double select the SETUP.EXE program. A series of screens (***Installation Wizard***) will appear and assist in the installation process.
4. Follow the on-screen prompts.

---

#### Note

It is recommended the default installation settings are used.

---

---

#### Note


Engineering Assistant version 6.3 or later requires the use of Microsoft® .NET Framework version 4.0 or later. If .NET version 4.0 is not currently installed, the software will be automatically installed during the Engineering Assistant installation. Microsoft .NET version 4.0 requires an additional 200 MB of disk space.

---

### Connecting to a personal computer (PC)

Figure 2-1 shows how to connect a computer to a .

**Figure 2-1: Connecting a PC to the 3051SMV**



A. Power supply  
B. HART® modem

### Procedure

1. Remove the cover from the field terminals side of the housing.
2. Power the device as outlined in [Connect wiring and power up](#).
3. Connect the HART modem cable to the PC.
4. On the side marked **Field Terminals**, connect the modem mini-grabbers to the two terminals marked **PWR/COMM**.
5. Launch the Rosemount 3051SMV Engineering Assistant.  
For more information on launching Engineering Assistant, see [Launching Engineering Assistant](#).
6. Once the configuration is complete, replace cover and tighten until metal contacts metal to meet flameproof/explosion-proof requirements.  
See [Cover installation](#) for more information.

## 2.3 Configuring flow

### 2.3.1 Engineering Assistant 6.3 or later

The Engineering Assistant is designed to guide you through the setup of the flow configuration of a Rosemount 3051SMV.


The **Flow Configuration** screens allow the user to specify the fluid, operating conditions, and information about the primary element including the inside pipe diameter. This information will be used by the Rosemount 3051SMV Engineering Assistant to create the flow configuration parameters that can be sent to the transmitter or saved for future use.

### NOTICE

To ensure correct operation, download the most current version of the Engineering Assistant software at [Rosemount Engineering Assistant 6 Software](#).

Figure 2-2 shows the path in which the Rosemount 3051SMV Engineering Assistant will guide the user through a flow configuration. If a natural gas, custom liquid, or custom gas option is chosen, an extra screen will be provided to specify the gas composition or fluid properties.

Figure 2-2: Flow Configuration Flowchart




## Online and Offline mode

The Engineering Assistant software can be used in two modes: **Online** and **Offline**.

In **Online** mode, the user can receive the configuration from the transmitter, edit the configuration, send the changed configuration to the transmitter, or save the configuration to a file. In **Offline** mode, the user may create a new flow configuration and save the configuration to a file or open and modify an existing file.

## 2.3.2 Basic navigation overview

Figure 2-3: Engineering Assistant basic navigation overview



The Engineering Assistant software can be navigated in a variety of ways. The letters below correspond to the letters shown in Figure 2-3.

- A. The navigation tabs contain the flow configuration information. In **Offline** mode, each tab will not become active until the required fields on the previous tab are completed. In **Online** mode, these tabs will be functional unless a change on a preceding tab is made.
- B. The **Reset** button will return each field within all of the flow configuration tabs (**Fluid Selection**, **Fluid Properties**, and **Primary Element Selection**) to the values initially displayed at the start of the configuration.
  - If editing a previously saved flow configuration, the values will return to those that were last saved.
  - If starting a new flow configuration, all entered values will be erased.
- C. The **Back** button is used to step backward through the flow configuration tabs.
- D. The **Next** button is used to step forward through the flow configuration tabs. The **Next** button will not become active until all required fields on the current page are completed.
- E. The **Help** button may be selected at any time to get a detailed explanation of the information required on the current configuration tab.
- F. Any configuration information that needs to be entered or reviewed will appear in this portion of the screen.
- G. These menus navigate to the **Configure Flow**, **Basic Setup**, **Device**, **Variables**, **Calibration**, and **Save/Send** tabs.
- H. These buttons navigate to **Config/Setup**, **Device Diagnostics**, or **Process Variables** sections.

## 2.3.3 Launching Engineering Assistant

Flow configuration for the Rosemount 3051SMV is achieved by launching the Engineering Assistant Software from the **START** menu.

The following steps show how to open the Engineering Assistant Software, and connect to a device:

### Procedure

1. Select **Start** → **All Programs** → **Engineering Assistant**.  
Engineering Assistant will open to screen as shown in [Figure 2-4](#).
2. If working offline, select the **Offline** button located on the bottom of the screen as shown in [Figure 2-4](#).


### Example

OR

If working online, select the **Search** button located on the lower right corner of the screen as shown in [Figure 2-4](#). Engineering Assistant will begin to search for online devices. When the search is completed, select the device to communicate with and select **Receive Configuration** button.

The **HART Master Level** can be set to either **Primary** or **Secondary**. **Secondary** is the default and should be used when the transmitter is on the same segment as another HART® communication device. The **COM Port** and **Device Address** may also be edited as needed.

**Figure 2-4: Engineering Assistant *Device Connection* Screen**




## 2.3.4 Preferences

The **Preferences** tab, shown in [Figure 2-5](#), allows the user to select the preferred engineering units to display and specify flow configuration information.

- Select the preferred engineering units. If units are needed other than the default U.S. or S.I. units, use the **Custom Units** setting. If **Custom Units** are selected, configure the **Individual Parameters** using the drop-down menus.
- Unit preferences selected will be retained for future Engineering Assistant sessions. Check the box to prevent the **Preferences** tab from being automatically shown in future sessions. The Preferences are always available by select the **Preferences** tab.

Figure 2-5: Preferences Tab




### 2.3.5

## Fluid Selection for database liquid/gas

The **Fluid Selection** tab (see Figure 2-6) allows the user to select the process fluid.

Figure 2-6: Fluid Selection Tab



### Note


The following example will show a flow configuration for an application with database gas air as the process fluid and a Rosemount 405C Conditioning Orifice Plate as the primary

element. The procedure to configure an application with other fluids and other primary elements will be similar to this example. Natural gases, custom liquids, and custom gases require additional steps during the configuration. See [Other fluid configurations](#) for more information.

### Procedure

1. Engineering Assistant may open to the **Preferences** tab. Using the tabs at the top of the screen, navigate to the **Fluid Selection** tab.
2. Expand the **Gas** category (select the + icon).
3. Expand the **Database Gas** category.
4. Select the appropriate fluid (**Air** for this example) from the list of database fluids.

**Figure 2-7: Fluid Selection Tab - Database Gas Air**



5. Enter the **Nominal Operating Pressure**, select the **Enter** or **Tab** key.

### Note

The **Nominal Operating Pressure** must be entered in absolute pressure units.

6. Enter the **Nominal Operating Temperature**, select the **Enter** or **Tab** key. Engineering Assistant will automatically fill in suggested operating ranges, as shown in [Figure 2-7](#). These values may be edited as needed by the user.
7. Verify the **Reference Conditions** are correct for the application. These values may be edited as needed.

### Note

**Reference pressure** and **temperature** values are used by Engineering Assistant to convert the flow rate from mass units to mass units expressed as standard or normal volumetric units.



8. Select **Next >** to proceed to the **Fluid Properties** tab.

**Example**

**Table 2-2: Liquids and Gases Database**

|                           |                         |                      |                   |
|---------------------------|-------------------------|----------------------|-------------------|
| 1,1,2,2-Tetrafluoroethane | Acrylonitrile           | Formaldehyde         | Nitrous Oxide     |
| 1,1,2-Trichloroethane     | Air                     | Formic Acid          | Nonanal           |
| 1,2,4-Trichlorobenzene    | Allyl Alcohol           | Furan                | n-Butane          |
| 1,2-Butadiene             | Ammonia                 | Helium-4             | n-Butanol         |
| 1,2-Propylene Glycol      | Aniline                 | Hydrazine            | n-Butyraldehyde   |
| 1,3-Propylene Glycol      | Argon                   | Hydrogen             | n-Butyronitrile   |
| 1,3,5-Trichlorobenzene    | Benzene                 | Hydrogen Chloride    | n-Decane          |
| 1,3-Butadiene             | Benzaldehyde            | Hydrogen Cyanide     | n-Dodecane        |
| 1,4-Dioxane               | Benzyl Alcohol          | Hydrogen Peroxide    | n-Heptadecane     |
| 1,4-Hexadiene             | Biphenyl                | Hydrogen Sulfide     | n-Heptane         |
| 1-Butene                  | Bromine                 | Isobutane            | n-Hexane          |
| 1-Decanol                 | Carbon Dioxide          | Isobutylbenzene      | n-Nonane          |
| 1-Decene                  | Carbon Monoxide         | Isohexane            | n-Octane          |
| 1-Dodecanol               | Carbon Tetrachloride    | Isoprene             | n-Pentane         |
| 1-Dodecene                | Chlorine                | Isopropanol          | Oxygen            |
| 1-Heptanol                | Chlorotrifluoroethylene | Melamine             | Pentafluoroethane |
| 1-Heptene                 | Chloroprene             | Methane              | Phenol            |
| 1-Hexadecanol             | Cycloheptane            | Methanol             | Propane           |
| 1-Hexene                  | Cyclohexane             | Methyl Acrylate      | Propadiene        |
| 1-Octanol                 | Cyclopentane            | Methyl Ethyl Ketone  | Pyrene            |
| 1-Octene                  | Cyclopentene            | Methyl Vinyl Ether   | Propylene         |
| 1-Nonanol                 | Cyclopropane            | m-Chloronitrobenzene | p-Nitroaniline    |
| 1-Pentadecanol            | Decanal                 | m-Dichlorobenzene    | Sorbitol          |
| 1-Pentanol                | Divinyl Ether           | Neon                 | Styrene           |
| 1-Pentene                 | Ethane                  | Neopentane           | Sulfur Dioxide    |
| 1-Undecanol               | Ethanol                 | Nitric Acid          | Toluene           |
| 2,2-Dimethylbutane        | Ethylamine              | Nitric Oxide         | Trichloroethylene |
| 2-Methyl-1-Pentene        | Ethylbenzene            | Nitrobenzene         | Vinyl Acetate     |
| Acetic Acid               | Ethylene                | Nitroethane          | Vinyl Chloride    |
| Acetone                   | Ethylene Glycol         | Nitrogen             | Vinyl Cyclohexane |
| Acetonitrile              | Ethylene Oxide          | Nitrogen Trifluoride | Vinylacetylene    |
| Acetylene                 | Fluorene                | Nitromethane         | Water             |

## 2.3.6 Fluid Properties

### Note


The **Fluid Properties** tab is an optional step and is not required to complete a flow configuration.

The **Fluid Properties** tab for the database gas air is shown in [Figure 2-8](#). The user may view the properties of the chosen fluid. The fluid properties are initially shown at nominal conditions. To view **Density**, **Compressibility**, and **Viscosity** of the selected fluid at other pressure and temperature values, enter a **Pressure** and **Temperature** and select **Calculate**.

### Note

Changing the **Pressure** and **Temperature** values on the **Fluid Properties** tab does not affect the flow configuration.

Figure 2-8: Fluid Properties Tab




## 2.3.7 Primary Element Selection

The **Primary Element Selection** tab shown in [Figure 2-9](#) allows the user to select the primary element that will be used with the Rosemount 3051SMV.

This database of primary elements includes:

- Rosemount proprietary elements such as the Rosemount Annubar™ and the conditioning orifice plate
- Standardized primary elements such as ASME, ISO, and AGA primary elements
- Other proprietary primary elements

Figure 2-9: *Primary Element Selection* tab




See the following procedure for an example of primary element configuration.

**Procedure**

1. Expand the **Conditioning Orifice** category.

Figure 2-10: *Primary Element Selection* Tab - 405C/3051SFC



2. Select **405C/3051SFC**.
3. Enter the **Measured meter tube diameter (pipe ID)** at a Reference Temperature. If the meter tube diameter cannot be measured, select a **Nominal pipe size** and **Pipe schedule** to input an estimated value for the meter tube diameter (U.S. units only).
4. If necessary, edit the **Meter tube material**.
5. Enter the **Line Size** and select the **Beta** of the Conditioning Orifice Plate.

The required primary element sizing parameters will be different depending on what primary element is selected.

6. If necessary, select a Primary Element **Material** from the drop-down menu.
7. Enter a calibration factor if a calibrated primary element is being used.

---

**Note**

A Joule-Thomson Coefficient can be enabled to compensate for the difference in process temperature between the orifice plate location and the process temperature measurement point. The Joule-Thomson Coefficient is available with ASME MFC-3M-2 (2004) or ISO 5167-2:2003 (E) orifice plates used with Database Gases, Superheated Steam, or AGA DCM/ISO Molar Composition Natural Gas. For more information on the Joule-Thomson Coefficient, reference the appropriate orifice plate standard.

---

8. Select **Next >** to advance to the **Save/Send Configuration** tab.

**Example**

---

**Note**

To be in compliance with appropriate national or international standards, beta ratios and differential producer diameters should be within the limits as listed in the applicable standards. The Engineering Assistant software will alert the user if a primary element value exceeds these limits, but will allow the user to proceed with the flow configuration.

---

## 2.3.8

### **Save/Send Configuration**

The **Save/Send Configuration** tab shown in [Figure 2-11](#) allows the user to view, save, and send the configuration information to the Rosemount 3051SMV with the fully compensated mass and energy flow feature board.

**Procedure**

1. Review the information under the **Flow Configuration** heading and **Device Configuration** heading.


---

**Note**

For more information on device configuration, see [Basic device configuration](#).

---

Figure 2-11: *Save/Send Configuration Tab (Offline Mode)*



2. Select the icon above each window to be taken to the appropriate screen to edit the configuration information. To return to the **Save/Send Configuration** tab, select **Save/Send** in the left menu.
3. When all information is correct, see [Sending a configuration in Offline mode](#) or [Sending a configuration in online mode](#).

#### Note

The user will be notified if the configuration has been modified since it was last sent to the transmitter. A warning message will be shown to the right of the **Send Flow Data** and/or **Send Device Data** check boxes.

## Sending a configuration in Offline mode

### Procedure

1. To send the configuration, select the **Send To** button.

#### Note

The **Send Flow Data** and/or **Send Device Data** check boxes can be used to select what configuration data is sent to the transmitter. If the check box is unselected, the corresponding data will not be sent.

The **Engineering Assistant Device Connection** screen will appear, see [Figure 2-12](#).

Figure 2-12: Engineering Assistant Device Connection Screen



2. Select the **Search** button located in the lower right corner of the screen. Engineering Assistant will begin to search for connected devices.
3. When the search is completed, select the device to communicate with and select **Send Configuration** button. Once the configuration is finished being sent to the device, a notification appears.
4. If finished with the configuration process, close Engineering Assistant.

**Note**

After the configuration is sent to the device, saving the configuration file is recommended. For more information on saving a configuration file, see [Save a configuration](#).

## Sending a configuration in online mode

**Procedure**

1. To send the configuration, select the **Send** button. Once the configuration is finished being sent to the device, a notification appears.
2. If finished with the configuration process, close Engineering Assistant.

**Note**

After the configuration is sent to the device, saving the configuration file is recommended. For more information on saving a configuration file, see [Save a configuration](#).

## Save a configuration

**Procedure**

1. To save the configuration, click **Save**.
2. Navigate to the save location for the configuration file, give the file a name, and click **Save**.

The configuration will be saved as an `.smv` file type.

## Send a saved configuration

### Procedure

1. To send a saved configuration, open Engineering Assistant in **Offline** mode and select **File** → **Open**.
2. Navigate to the saved .smv file to be sent. Select **Open**.  
The **Engineering Assistant Device Connection** screen will appear. See [Figure 2-12](#).
3. Select the **Search** button located in the lower right corner of the screen.  
Engineering Assistant will begin to search for connected devices.
4. When the search is completed, select the device to communicate with and select **Send Configuration** button.  
Once the configuration is finished being sent to the device, a notification appears.
5. If finished with the configuration process, close Engineering Assistant.

## 2.3.9 Other fluid configurations


### Natural gas AGA No. 8 detail characterization or ISO 12213, molar composition flow configuration

#### Procedure

1. Expand the **Gas** category.
2. Expand the **Natural Gas** category.
3. Select **AGA Report No. 8 Detail Characterization Method** or **ISO 12213, Molar Composition Method**.
4. Select **Next >** to proceed to the **Fluid Composition** tab.

[Figure 2-13](#) shows an example of the **Fluid Composition** tab for **AGA Report No. 8 Detail Characterization Method**. The **ISO 12213, Molar Composition Method Fluid Composition** tab will require the same information.

**Figure 2-13: Fluid Composition Tab**



5. In the **Available Components** window, select the required components and move them into the **Selected Components** window using the >> button.  
The << button moves the components back to the **Available Components** window.  
The **Clear** button moves all components back to the **Available Components** window.
6. After all required components are in the **Selected Components** window, begin assigning the percent composition of each component in the **Mole %** column.

**Note**

These percent composition values should add to 100 percent. If they do not, select the **Normalize** button. This will adjust the mole percentages proportionally to a total of 100 percent.

7. Enter the **Nominal Operating Pressure**, then the **Nominal Operating Temperature** as the entry blanks become available.  
Engineering Assistant will automatically fill in suggested operating ranges. These values may be edited by the user.

**Note**

In order to comply with the AGA requirements, the calculation accuracy must be within  $\pm 50$  ppm ( $\pm 0.005\%$ ). This is stated in AGA Report No. 3, Part 4, Section 4.3.1. The pressure and temperature operating ranges will be autofilled to comply with the standard.

8. Select **Next >**.  
This will bring the user to the **Fluid Properties** tab.
9. Proceed with the steps in [Fluid Properties](#).

## Natural gas American Gas Association (AGA) No. 8 gross characterization flow configuration method 1, method 2, and natural gas International Organization for Standardization (ISO) 12213, physical properties (SGERG 88) flow configuration

### Procedure

1. Expand the **Gas** category.
2. Select **AGA No. 8 Gross Characterization Method 1**, **AGA No. 8 Gross Characterization Method 2**, or **ISO 12213, Physical Properties (SGERG 88)**.
3. Select **Next** to proceed to the **Fluid Composition** tab.
4. Enter the required data for the **Natural Gas Characterization Method** that was selected in [Step 2](#).

Required data for each method is listed in [Table 2-3](#).

**Table 2-3: Required and optional data for Natural Gas Characterization Methods**

| Characterization method                          | Required data   | Optional data  |
|--|---|--|
| AGA Report No. 8 Gross Characterization Method 1 | <ul style="list-style-type: none"> <li>• Relative Density<sup>(1)</sup></li> <li>• Mole Percent CO<sub>2</sub></li> <li>• Volumetric Gross Heating Value<sup>(2)</sup></li> </ul> | <ul style="list-style-type: none"> <li>• Mole Percent CO</li> <li>• Mole Percent Hydrogen</li> </ul> |
| AGA Report No. 8 Gross Characterization Method 2 | <ul style="list-style-type: none"> <li>• Relative Density<sup>(1)</sup></li> <li>• Mole Percent CO<sub>2</sub></li> <li>• Mole Percent Nitrogen</li> </ul>                        | <ul style="list-style-type: none"> <li>• Mole Percent CO</li> <li>• Mole Percent Hydrogen</li> </ul> |



**Table 2-3: Required and optional data for Natural Gas Characterization Methods**  
*(continued)*

| Characterization method                   | Required data   | Optional data  |
|---|---|--|
| ISO 12213, Physical Properties (SGERG 88) | <ul style="list-style-type: none"> <li>• Relative Density<sup>(1)</sup></li> <li>• Mole Percent CO<sub>2</sub></li> <li>• Volumetric Gross Heating Value<sup>(2)</sup></li> </ul> | <ul style="list-style-type: none"> <li>• Mole Percent CO</li> <li>• Mole Percent Hydrogen</li> </ul> |

(1) Reference conditions for the relative density are 60 °F (15.56 °C) and 14.73 psia (101.56 kPa).

(2) Reference conditions for the molar gross heating value are 60 °F (15.56 °C) and 14.73 psia (101.56 kPa) and reference conditions for molar density are 60 °F (15.56 °C) and 14.73 psia (101.56 kPa).

5. If appropriate, enter the optional data for the **Natural Gas Characterization Method** that was selected in [Step 2](#).  
Optional data for each method is listed in [Table 2-3](#).
6. Enter the **Nominal Operating Pressure**, then the **Nominal Operating Temperature** as the entry blanks come available.  
Engineering Assistant will automatically fill in suggested operating ranges. Note that these values may be edited by the user.
7. Select **Next**.  
This will open the **Fluid Properties** tab.
8. Proceed with the steps in [Fluid Properties](#).

## Ideal Gas


The **Ideal Gas** option should be used when the fluid behavior can be modeled by the ideal gas law. This option uses a modified version of the ideal gas law with a constant value of compressibility. The default value for compressibility is 1.00, but you can edit it. To use an ideal gas enter in the operating **Pressure** and **Temperature** followed by either the **Density**, **Specific Gravity**, or **Molecular Weight**.

### Procedure

1. Expand the **GAS** category.
2. Select the **Ideal Gas** option.
3. Enter the **Nominal Operating Pressure** and **Temperature** Ranges.  
Engineering Assistant will use these ranges to identify the pressure and temperature values at which the fluid properties are required.

For the ideal gas being used, enter the **Nominal Density**, **Specific Gravity**, or **Molecular Weight** using the drop-down menu. Once these are entered the other data entry fields, **Compressibility** and **Viscosity**, are enabled as shown on [Figure 2-14](#).

Figure 2-14: Fluid Selection Ideal Gas




4. Adjust the **Compressibility** and **Viscosity** to fit the ideal gas of the process.
5. Select **Next** to proceed to the **Fluid Properties** tab.

**Note**

The **Fluid Properties** tab is an optional step and is not required to complete a flow configuration. The **Fluid Properties** tab for the database gas air is shown in [Figure 2-15](#). The user may view the properties of the chosen fluid. The fluid properties are initially shown at nominal conditions. To view **Density**, **Compressibility**, and **Viscosity** of the selected fluid at other pressure and temperature values, enter a **Pressure** and **Temperature** and select **Calculate**. Changing the pressure and temperature values on the **Fluid Properties** tab does not affect the flow configuration.

Figure 2-15: Fluid Properties Tab



6. Select **Next** to continue with the flow configuration on the **Primary Element Selection** tab.
7. Proceed with the steps in [Primary Element Selection](#).

## Custom Gas

Use the **Custom Gas** option should be used for fluids not in the database, such as proprietary fluids or gas mixtures.

To properly calculate the fluid properties, the **Compressibility** factor or **Density** needs to be entered at specific **Pressure** and **Temperature** values based on the operating ranges entered by the user. The **Pressure** and **Temperature** values may be edited as needed. The editable values are shown in fields with white backgrounds. For best performance, it is recommended that, whenever possible, the **Compressibility** or **Density** values be entered at the suggested **Pressure** and **Temperature** values.

To ease entering the **Compressibility/Density** or **Viscosity** values, data can be copied from a spreadsheet and pasted into the grid. The recommended process is to copy the **Pressure** and **Temperature** values from the table on the **Engineering Assistant** screen to assist in computing the **Density** or **Compressibility** values. Once the compressibility or density values are computed, they may then be copied from the spreadsheet and pasted into the grid on the **Custom Gas Fluid Properties** tab.

### Procedure

1. Expand the **GAS** category.
2. Select the **Custom Gas** option.
3. Enter the **Nominal Operating Pressure** and **Temperature** Ranges. Engineering Assistant will use these ranges to identify the pressure and temperature values at which the fluid properties are required.
4. Select **Next** to proceed to the **Custom Gas Fluid Properties** tab.
5. Enter the **Molecular weight** of the **Custom Gas**.  
When the **Molecular weight** of the gas is entered, the other data entry fields on the tab are enabled as shown in [Figure 2-16](#).
6. Select either **Density** or **Compressibility** and enter data.

---


### Note

All **Pressure** and **Temperature** values may be edited except the minimum and maximum values. The minimum and maximum values were set on the **Fluid Selection** tab.

---

7. Enter the **Density** or **Compressibility** at reference conditions.
8. Enter the **Custom Gas Viscosity** at the given temperatures.  
Note that all temperature values may be edited except the minimum and maximum temperatures.
9. Enter the **Custom Gas Isentropic Exponent**.
10. Select **Next** to continue with the flow configuration on the **Primary Element Selection** tab.
11. Proceed with the steps in [Primary Element Selection](#).

Figure 2-16: Custom Gas Fluid Properties Tab



## Custom Liquid (Density [T])

The **Custom Liquid** option should be used for fluids not in the database such as proprietary fluids.

### Procedure


1. Expand the **LIQUID** category.
2. Expand the **Custom Liquid** category.
3. Select the **Custom Liquid (Density [T])** option.
4. Enter the **Nominal** and **Operating** Temperature Range.  
Engineering Assistant will use this range to identify the temperature values at which the fluid properties are required.
5. Select **Next** to continue the flow configuration on the **Fluid Properties** tab.
6. Enter the **Custom Liquid Density** at the given temperatures.

### Note

All temperature values may be edited except the minimum and maximum temperatures.

7. Enter the **Reference density** at the reference **Temperature**.
8. Enter the **Custom Liquid Viscosity** at the given temperatures.  
Note that all temperature values may be edited except the minimum and maximum temperatures. The minimum and maximum values were set on the **Fluid Selection** tab.
9. Proceed with the steps in [Primary Element Selection](#).

Figure 2-17: Custom Liquid (Density [T]) Fluid Properties Tab



## 2.4 Basic device configuration

**Mass and energy flow fast keys** 1, 3

**Direct process variable output fast keys** 1, 3

This section provides procedures for configuring the basic requirements to commission the Rosemount 3051SMV. The **Basic Setup** tab, shown in [Figure 2-18](#), can be used to perform all of the required transmitter configuration. The complete list of Field Communicator Fast Keys for basic setup are shown in [Communication device Fast Keys](#).

Based on the configuration ordered, some measurements (i.e. static pressure, process temperature) and/or calculation types (i.e. mass, volumetric, and energy flow) may not be available for all fluid types. Available measurements and/or calculation types are determined by the multivariable type and measurement type codes ordered. See the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#) for more information.

All screens in this section are shown for multivariable type M (fully compensated mass and energy flow) with measurement type 1 (differential pressure, static pressure, and process temperature). Field Communicator Fast Keys are given for both multivariable type M and P (direct process variable output) with measurement type 1. Field Communicator Fast Keys and screens for other multivariable types and measurement types may vary.

### Note

All screenshots in this section will be shown using AMS Device Manager. Engineering Assistant screens are similar and the instructions shown here apply to both AMS Device Manager and Engineering Assistant.

When using Engineering Assistant, a **Reset Page** button will be shown. In online mode, the **Reset Page** button will return all values on tab to the initial values received from the device before the start of the configuration. If editing a previously saved configuration, the **Reset**

**Page** button will return all values on tab to those that were last saved. If starting a new configuration, all entered values on tab will be erased.


## NOTICE

When information is edited on any AMS Device Manager tab, it will be highlighted in yellow. Edited information is not sent to the transmitter until the **Apply** or **OK** button is selected.

### 2.4.1 Units of measure

If a unit of measure is edited and the **Apply** button is selected, the unit of measure will be changed in the device memory and on screen, but the value may take up to 30 seconds to be updated on the AMS Device Manager screen.

**Figure 2-18: Basic Setup Tab**



- Verify the Device Tag information. The tag information is used to identify specific transmitters on the 4–20 mA loop. This tag information may be edited.
- Under the **Flow Rate** heading (fully compensated mass and energy flow feature board only), the type of flow calculation (**Mass** or **Volumetric**) is displayed by the indicators on the right side of the box. The Flow Calculation Type may be edited by selecting the **Configure Flow Calculation Type** button. The **Damping** and Flow Rate Unit may also be edited under this heading.

#### Note

The flow calculation within the device uses undamped process variables. Flow rate damping is set independently of measured process variables.

- Under the **Energy Rate** heading (fully compensated mass and energy flow feature board only), the **Unit** and **Damping** for the Energy Rate may be edited.

#### Note

Energy rate calculations are only available for steam and natural gas. The energy rate calculation within the device uses undamped process variables. Energy rate damping is set independently of flow rate damping or measured process variables.

- Under the **Differential Pressure** heading, the **Units** and **Damping** for the Differential Pressure may be edited.
- Under the **Static Pressure** heading, the **Absolute Unit** and **Gage Unit** and static pressure **Damping** may be edited.

---

#### Note

Both absolute and gage pressure are available as variables. The type of transmitter ordered will determine which variable is measured and which is calculated based on the user defined atmospheric pressure. For more information on configuring the atmospheric pressure, see [Static pressure](#). Since only one of the static pressures is actually being measured, there is a single **Damping** setting for both variables which may be edited under the **Static Pressure** heading.

---

- Under the **Process Temperature** heading, the **Unit** and **Damping** for the Process Temperature may be edited.
- Under the **Module Temperature** heading, the **Unit** for the sensor module temperature may be set. The sensor module temperature measurement is taken within the module, near the differential pressure and/or static pressure sensors and can be used to control heat tracing or diagnose device overheating.
- Under the **Analog Output** heading, the **Primary Variable** can be selected from the drop down menu and the **Upper Range Value** and **Lower Range Value** (4 and 20 mA points) for the primary variable may be edited.
- Under the **Totalizer Setup** heading (fully compensated mass and energy flow feature board only), the Totalizer can be configured by selecting the **Configure Totalizer** button. This button allows the user to select the variable to be totalized. The Totalizer **Unit** may also be edited under this heading.

## 2.5 Detailed device configuration


### 2.5.1 Model identification

**Mass and energy flow fast keys** 1, 3, 5

**Direct process variable output fast keys** 1, 3, 5

The **Identification** tab displays the device identification information on one screen. The fields with white backgrounds may be edited by the user.

Figure 2-19: Device → Identification tab



## 2.5.2 Alarm and saturation

The transmitter automatically and continuously performs self-diagnostic routines.

If the self-diagnostic routines detect a failure, the transmitter drives the output to the configured alarm value. The transmitter will also drive the output to configured saturation values if the primary variable goes outside the 4–20 mA range values.

You can configure the alarm and saturation settings using Engineering Assistant, AMS Device Manager, or a communication device. The alarm direction can be configured using the hardware switch on the feature board. See [Configure security \(write protect\)](#) for more information on the hardware switch.

The Rosemount 3051SMV has three options for alarm and saturation levels:

- Rosemount (Standard), see [Table 2-4](#)
- NAMUR, see [Table 2-5](#)
- Custom (user-defined), see [Table 2-6](#)

Table 2-4: Rosemount (Standard) Alarm and Saturation Values

| Level | Saturation | Alarm      |
|-------|------------|------------|
| Low   | 3.9 mA     | ≤ 3.75 mA  |
| High  | 20.8 mA    | ≥ 21.75 mA |



**Table 2-5: NAMUR-Compliant Alarm and Saturation Values**

| Level | Saturation | Alarm     |
|-------|------------|-----------|
| Low   | 3.8 mA     | ≤ 3.6 mA  |
| High  | 20.5 mA    | ≥ 22.5 mA |

**Table 2-6: Custom Alarm and Saturation Values**

| Level | Saturation        | Alarm             |
|-------|-------------------|-------------------|
| Low   | 3.7 mA — 3.9 mA   | 3.6 mA — 3.8 mA   |
| High  | 20.1 mA — 22.9 mA | 20.2 mA — 23.0 mA |

The following limitations exist for custom levels:

- **Low alarm** level must be less than the low saturation level
- **High alarm** level must be higher than the high saturation level
- Alarm and saturation levels must be separated by at least 0.1 mA

**Related information**

[Alarm and Saturation Levels configuration](#)


**Alarm and Saturation Levels configuration**

**Mass and energy flow fast keys** 1, 4, 2, 6, 6

**Direct process variable output fast keys** 1, 4, 2, 6, 6

The **Alarm/Sat Levels** tab allows the **Alarm and Saturation Levels** to be configured. To change **Alarm/Saturation Levels** settings, select the **Config Alarm/Sat Levels** button.

**Figure 2-20: Device - Alarm/Sat Levels Tab**



## Alarm level verification

Verify the transmitter alarm level before returning the transmitter to service if you change alarm and saturation levels.

This feature is also useful in testing the reaction of the control system to a transmitter in an alarm state. To verify the transmitter alarm values, perform a loop test and set the transmitter output to the alarm value (see [Alarm and saturation](#) and [Analog output loop test](#)).

## Variable saturation behavior

The transmitter's analog output may respond differently based on which measurement goes outside the sensor limits.

This response will also depend on the device configuration. [Table 2-7](#) lists the behaviors of the analog output under different conditions.

**Table 2-7: Variable Saturation Behavior**

| Primary variable                             | Action  | Analog output behavior  |
|--|---|---|
| Flow or Energy Flow                          | Differential Pressure goes outside the sensor limits              | Analog output goes to <b>High Saturation</b> or <b>Low Saturation</b>   |
| Flow or Energy Flow                          | Absolute Pressure or Gage Pressure goes outside the sensor limits | Analog output does not saturate   |
| Flow or Energy Flow                          | Process Temperature goes outside the user defined sensor limits   | <b>Temperature</b> mode is <b>Normal</b> : Analog output goes into <b>High Alarm</b> or <b>Low Alarm</b> .<br><b>Temperature</b> Mode is <b>Backup</b> : The <b>Process Temperature (Temp)</b> will go into Backup mode and be fixed at the user defined value. Analog output will not saturate or go into alarm. |
| Differential Pressure (DP)                   | Differential Pressure goes outside the sensor limits              | Analog output goes to <b>High</b> or <b>Low Saturation</b>  |
| Absolute Pressure (AP) or Gage Pressure (GP) | Absolute Pressure or Gage Pressure goes outside the sensor limits | Analog output goes to <b>High Saturation</b> or <b>Low Saturation</b>   |
| Process Temp                                 | Process Temperature goes outside the user defined sensor limits   | Direct process variable output: Analog output goes to High Saturation or Low Saturation<br>Mass and Energy Flow: Analog output goes to <b>High Alarm</b> or <b>Low Alarm</b>  |


### 2.5.3 Variable mapping

Mass and energy flow fast keys 1, 4, 3, 4

Direct process variable output fast keys 1, 4, 3, 4

The **Variable Mapping** tab is used to define which process variable will be mapped to each HART variable. The **Primary Variable** represents the 4–20 mA analog output signal while the **2nd Variable**, **3rd Variable**, and **4th Variable** are digital. To edit the variable assignments, select the appropriate process variables from the drop-down menus and select **Apply**.

Figure 2-21: Device - Variable Mapping Tab



## 2.5.4 LCD display


**Mass and energy flow fast keys** 1, 3, 8

**Direct process variable output fast keys** 1, 3, 8

The LCD display features a four-line display and a 0–100 percent scaled bar graph. The first line of five characters displays the output description, the second line of seven digits displays the actual value, and the third line of six characters displays engineering units. The fourth line displays **Error** when there is a problem detected with the transmitter. The LCD display can also show diagnostic messages. These diagnostic messages are listed in [LCD display diagnostics](#).

The **LCD** tab allows the user to configure which variables will be shown on the LCD display. Select the check box next to each variable to select a variable for display. The transmitter will scroll through the selected variables, showing each for three seconds.

Figure 2-22: Device - LCD Tab




## 2.5.5 Communication setup

**Mass and energy flow fast keys** 1, 4, 3, 3

**Direct process variable output fast keys** 1, 4, 3, 3

The **Communication (Comm) Setup** tab allows the settings for **Burst Mode** and **Multidrop** communications to be configured.

Figure 2-23: Device - Comm Setup Tab



## Burst mode

When **Burst Mode Enable** is set to **On**, the Rosemount 3051SMV sends up to four HART® variables to the control system without the control system polling for information from the transmitter.

When operating with **Burst Mode Enable** set to **On**, the transmitter will continue to output a 4–20 mA analog signal. Because the HART protocol features simultaneous digital and analog data transmission, the analog value can drive other equipment in the loop while the control system is receiving the digital information. **Burst** mode applies only to the transmission of dynamic data (process variables in engineering units, primary variable in percent of range, and/or analog output), and does not affect the way other transmitter data is accessed.

Access to information that is not burst can be obtained through the normal poll/response method of HART communication. A communication device, AMS Device Manager, Engineering Assistant, or the control system may request any of the information that is normally available while the transmitter is in **Burst** mode.

## Enabling Burst mode

**Mass and energy flow fast keys** 1, 4, 3, 3, 3

**Direct process variable output fast keys** 1, 4, 3, 3, 3

To enable **Burst** mode, select **On** from the **Burst Mode Enable** drop-down menu under the **Burst Mode** heading.

## Choosing a Burst Option

|  |               |
|--|---------------|
| Mass and energy flow Fast Keys           | 1, 4, 3, 3, 4 |
| Direct process variable output Fast Keys | 1, 4, 3, 3, 4 |

This parameter selects the information to be burst. Make a selection from the **Burst Option** drop-down menu under the **Burst Mode** heading. The **Dyn vars/current** option is the most common, because it is used to communicate with the Rosemount 333 HART® Tri-Loop™.

**Table 2-8: Burst Options**

| HART command | Burst Option                 | Description                               |
|--------------|------------------------------|---|
| 1            | <b>PV</b>                    | Primary variable                          |
| 2            | <b>% range/current</b>       | Percent of range and milliamp output      |
| 3            | <b>Dyn vars/current</b>      | All process variables and milliamp output |
| 9            | <b>Device vars w/ status</b> | Burst variables and status information    |
| 33           | <b>Device variables</b>      | Burst variables                           |

## Choosing *Burst Variable Slot Definition*

**Mass and energy flow fast keys** 1, 4, 3, 3, 5

**Direct process variable output fast keys** 1, 4, 3, 3, 5

If the **Burst Option Device vars w/ status** or **Device variables** is selected, the user may select the four variables that will be burst. These are defined in **Slot 0**, **Slot 1**, **Slot 2**, and **Slot 3** under the **Burst Variable Slot Definition** heading. The variables defined in **Slot 1**, **Slot 2**, **Slot 3**, and **Slot 4** can be different than the variables mapped to the **Primary Variable**, **2nd Variable**, **3rd Variable**, and **4th Variable** outputs.

## Multidrop communication

Multidropping transmitters refers to the connection of several transmitters to a single communications transmission line.

### Note


Figure 2-24 shows a typical multidrop network. This figure is not intended as an installation diagram.

Communication between the host and the transmitters takes place digitally with the analog output of the transmitters deactivated.

### Note

A transmitter in **Multidrop** mode with **Loop Current** Mode disabled has the analog output fixed at 4 mA.

Figure 2-24: Typical Multidrop Network



- A. Power supply
- B. HART modem

## Enable multidrop communication

**Mass and energy flow fast keys** 1, 4, 3, 3, 1

**Direct process variable output fast keys** 1, 4, 3, 3, 1

The transmitter is set to address zero (0) at the factory, which allows operation in the standard point-to-point manner with a 4–20 mA output signal. To activate multidrop communication, change the transmitter address to 1–15 for HART 5 hosts or 1–63 for HART 6 hosts. This change deactivates the 4–20 mA analog output, sending it to a fixed value of 4 mA. It also disables the failure alarm signal, which is controlled by the **High (HI)/Low (LO)**

alarm switch position on the feature board. Failure signals in multidropped transmitters are communicated through HART messages.

## Loop Current mode

**Mass and energy flow fast keys** 1, 4, 3, 3, 2

**Direct process variable output fast keys** 1, 4, 3, 3, 2

When using multidrop communication, the **Loop Current Mode** drop-down menu defines how the 4–20 mA analog output behaves. When loop current mode is disabled, the analog output will be fixed at 4 mA. When the **Loop Current Mode** is enabled, the analog output will follow the primary variable.


## 2.5.6 Materials of construction

**Mass and energy flow fast keys** 1, 4, 4, 2

**Direct process variable output fast keys** 1, 4, 4, 2

The **Materials of Construction** tab allows the materials of construction, remote seal, and equipped sensor information to be viewed. The parameters shown in white boxes may be edited by the user, but do not affect the operation of the device.

**Figure 2-25: Device - Materials of Construction Tab**




## 2.5.7 Flow configuration parameters

**Mass and energy flow fast keys** 1, 4, 4, 3

Fully compensated mass and energy flow feature board only.

The **Flow Configuration (Config) Parameters** tab allows the **Fluid**, **Primary Element** and **Pipe Diameter** used in the flow configuration to be viewed. These values may only be edited using Engineering Assistant version 6.3 or later.

Figure 2-26: Device - Flow Config Parameters Tab



## 2.6 Variable configuration

### 2.6.1 Flow rate

Mass and energy flow fast keys

1, 4, 1, 1


#### Note

Fully compensated mass and energy flow feature board only

The **Flow** tab is used to configure the settings associated with the flow variable. Use the Engineering Assistant to configure fluid and primary element information which defines the flow calculation.



Figure 2-27: Variables → Flow Tab



- Under the **Flow Rate Setup** heading, the type of flow calculation is indicated by the check boxes next to either **Mass Flow Calculation** or **Volumetric Flow Calculation**. To edit the flow calculation type, select the **Configure Flow Calculation Type** button.
- Edit the Flow Rate Units and **Damping** value as needed. The flow calculation within the device uses undamped process variables. Flow rate damping is set independently of the measured process variables.

#### Note

If the flow calculation type is changed, the totalizer will be stopped and reset automatically.

- Under the **Low Flow Cutoff** heading, edit the current **Minimum Differential Pressure (DP)** Value as needed. The unit for this value is the user-selected DP unit. If the measured DP value is less than the **Minimum DP** value, the transmitter will calculate the Flow Rate value to be zero.
- The **Upper Sensor Limit**, **Lower Sensor Limit**, and **Minimum Span** can be viewed under the **Flow Rate Sensor Limits** heading.

#### Note

If the flow rate is configured as the primary variable and is being output via the 4–20 mA signal, verify the 4–20 mA range (**Lower range value [LRV]** and **upper range value [URV]**) after completing the custom unit configuration. For more information on verifying the 4–20 mA range, see [Basic device configuration](#).

Follow these steps to configure a custom unit:

#### Procedure

1. **Custom Unit:** Enter the desired custom unit label to be displayed for the flow rate. Up to five characters including letters, numbers, and symbols can be entered in the custom unit field.

#### Note

It is recommended that the **Custom Unit** be entered in uppercase letters. If lowercase letters are entered, the LCD display will show upper case letters. Additionally, the following special characters are recognized by the LCD display: hyphens (“-”), percent symbols (“%”), asterisks (“\*”), forward slashes (“/”) and spaces. Any other character entered for the **Custom Unit** will be displayed as an asterisk

("\*") on the LCD display. The following warning will be returned indicating these changes: Custom Unit contains characters that will display in upper case or asterisks on LCD display. The DCS will display as entered.

2. **Base Unit:** From the drop-down menu, select a base unit to be used for the custom unit relationship.
3. **Base per Custom:** Enter a numeric value that represents the number of base units per one custom unit.

The Rosemount 3051SMV uses the following convention: Base per Custom =

$$\frac{\text{Number of Base Units}}{1 \text{ Custom Unit}}$$

Example

Custom Unit: kg Base Unit: g

Because:

1 kg (Kilogram) = 1000 g (Grams)

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{1000 \cdot \text{g}}{1 \cdot \text{kg}} = 1000$$

The values of **Base per Custom** for common flow units are shown in [Table 2-9](#).

4. Select **Apply**.
5. **Flow Rate Unit:** From the drop-down menu, select the custom unit that was created in [Step 2](#).

#### Note

The **Custom Unit** may not be available as a selection in the **Flow Rate Unit** drop-down menu until the drop-down menu is refreshed. To refresh the drop-down menu, navigate to the **Basic Setup** tab and then return to the **Variables** → **Flow** tab.

**Table 2-9: Common Custom Units - Flow**

| Custom Unit                                     | Base Unit   | Base per Custom |
|---|-------------|-----------------|
| Barrels per Minute (BBL/M)                      | bbl/h       | 60              |
| Cubic Meters per Day (CUM/D)                    | Cum/h       | 0.041667        |
| Millions of Cubic Meters per Day (MMCMD)        | Cum/h       | 41666.7         |
| Millions of Gallons per Day (MGD)               | gal/d       | 1000000         |
| Millions of Liters per Day (MML/D)              | L/h         | 41666.7         |
| Millions of Standard Cubic Feet per Day (MMCFD) | StdCuft/min | 694.444         |
| Normal Cubic Meters per Day (NCM/D)             | NmlCum/h    | 0.041667        |
| Normal Cubic Meters per Minute (NCM/M)          | NmlCum/h    | 60              |
| Short Tons per Day (STOND)                      | lb/d        | 2000            |
| Short Tons per Hour (STONH)                     | lb/h        | 2000            |
| Standard Cubic Feet per Day (SCF/D)             | StdCuft/min | 0.000694        |
| Standard Cubic Feet per Hour (SCF/H)            | StdCuft/min | 0.016667        |

**Table 2-9: Common Custom Units - Flow (continued)**

| Custom Unit                                       | Base Unit   | Base per Custom |
|---|-------------|-----------------|
| Standard Cubic Feet per Second (SCF/S)            | StdCuft/min | 60              |
| Standard Cubic Meters per Day (SCM/D)             | StdCum/h    | 0.041667        |
| Thousands of Gallons per Day (KGD)                | gal/d       | 1000            |
| Thousands of Pounds per Hour (KLB/H)              | lb/h        | 1000            |
| Thousands of Standard Cubic Feet per Day (KSCFD)  | StdCuft/min | 0.694444        |
| Thousands of Standard Cubic Feet per Hour (KSCFH) | StdCuft/min | 16.6666         |

If conversion factor tables or internet search engines are used to determine the **Base per Custom** value, it is important to enter the **Custom Unit** in the **From** field and the **Base Unit** in the **To** Field. An example of this is shown below:

Convert what quantity?

From:

- cubic dekameter/hour
- cubic dekameter/minute
- cubic dekameter/second
- cubic foot/day
- cubic foot/hour
- cubic foot/minute
- cubic foot/second
- cubic inch/day
- cubic inch/hour
- cubic inch/minute
- cubic inch/second

To:

- cubic dekameter/hour
- cubic dekameter/minute
- cubic dekameter/second
- cubic foot/day
- cubic foot/hour
- cubic foot/minute
- cubic foot/second
- cubic inch/day
- cubic inch/hour
- cubic inch/minute

**Result:**

To calculate the **Base per Custom** value for a **Custom Unit** not shown in [Table 2-9](#), see one of the following examples:

- Mass/volume conversion example: [Mass/volume conversion example](#)
- Time conversion example: [Time conversion example](#)
- Mass/volume and time conversion example: [Mass/volume and time conversion example](#)

### Mass/volume conversion example

To find the **Base per Custom** relationship for a custom unit of kilograms per hour (kg/h) and a base unit of grams per hour (g/h), input the following:

**Custom Unit** = kg/h **Base Unit** = g/h

Because:

1 kg (Kilogram) = 1000 g (Grams)


$$\text{Then: } 1 \text{ kg/h} = \frac{1 \cdot \text{kg}}{1 \cdot \text{h}} \times \frac{1000 \cdot \text{g}}{1 \cdot \text{kg}} = 1000 \text{ g/h}$$

1 kg/h = 1000 g/h

Therefore:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{1000 \cdot \text{g/h}}{1 \cdot \text{kg/h}} = 1000$$

Figure 2-28: Flow Rate Custom Unit - Mass/Volume Conversion Example



### Time conversion example

To find the **Base per Custom** relationship for a custom unit of standard cubic feet per hour (scf/h) and a **Base Unit** of standard cubic feet per minute (StdCuft/min), input the following:

**Custom Unit** = scf/h **Base Unit** = StdCuft/min

Because:

1 h (Hour) = 60 min (Minutes)


$$\text{Then: } 1 \text{ scf/h} = \frac{1 \cdot \text{scf}}{1 \cdot \text{h}} \times \frac{1 \cdot \text{h}}{60 \cdot \text{min}} = 0.016667 \text{ StdCuft/min}$$

$$1 \text{ scf/h} = 0.016667 \text{ StdCuft/min}$$

Therefore:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{0.016667 \cdot \text{StdCuft/min}}{1 \cdot \text{scf/h}} = 0.016667$$

Figure 2-29: Flow Rate Custom Unit - Time Conversion Example



### Mass/volume and time conversion example

To find the **Base per Custom** relationship for a custom unit of standard millions of standard cubic feet per day (mmcf) and a base unit of standard cubic feet per minute (StdCuft/min), input the following:

**Custom Unit** = mmcf **Base Unit** = StdCuft/min

Because:

1 mmcf (Millions of Standard Cubic Feet) = 1000000 StdCuft (Standard Cubic Feet) and

1 d (Day) = 1440 min (Minutes)

Then:


$$1 \text{ mmcf} = \frac{1 \cdot \text{mmcf}}{1 \cdot \text{d}} \times \frac{1000000 \cdot \text{StdCuft}}{1 \cdot \text{mmcf}} \times \frac{1 \cdot \text{d}}{1440 \cdot \text{min}} = 694.444 \text{ StdCuft/min}$$

$$1 \text{ mmcf} = 694.444 \text{ StdCuft/min}$$

Therefore:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{694.444 \cdot \text{StdCuft/min}}{1 \cdot \text{mmcf}} = 694.444$$

Figure 2-30: Flow Rate Custom Units - Mass/Volume and Time Conversion Example



Under the **Custom Units Setup** heading, the user may configure a **Custom Unit** for the flow rate measurement. Custom units allow the flow rate to be displayed in units of measure that are not standard in the Rosemount 3051SMV.

## 2.6.2 Energy rate

### Mass and energy flow fast keys

1, 4, 1, 2

Fully compensated mass and energy flow feature board only.

#### Note

Energy Rate calculations are only available for certain fluid types.

The **Energy** tab allows the user to configure the settings associated with the energy flow.

- Under the **Energy Rate Setup** heading, edit the **Energy Rate Units** and **Damping** values as needed. The energy rate calculation within the device uses undamped process variables. Energy rate damping is set independently of flow rate damping and measured process variables.
- Under the **Custom Units Setup** heading, the user may configure a custom unit for the energy rate measurement. Custom units allow the energy rate to be displayed in units of measure that are not standard in the Rosemount 3051SMV.

#### Note

If the energy rate is configured as the primary variable and is being output via the 4-20 mA signal, verify the 4-20 mA range (**lower range value [LRV]** and **upper range value [URV]**) after completing the custom unit configuration. For more information on verifying the 4-20 mA range, see [Basic device configuration](#).

To configure a custom unit:

#### Procedure

1. **Custom Unit:** Enter the desired custom unit label to be displayed for the energy rate. Up to five characters including letters, numbers, and symbols can be entered in the **Custom Unit** field.

**Note**

It is recommended that the **Custom Unit** be entered in upper case letters. If lower case letters are entered, the LCD display will show upper case letters. Additionally, the following special characters are recognized by the LCD display: hyphens ("-"), percent symbols ("%"), asterisks ("\*"), forward slashes ("/") and spaces. Any other character entered for the **Custom Unit** will be displayed as an asterisk ("\*") on the LCD display. The following warning will be returned indicating these changes: Custom Unit contains characters that will display in upper case or asterisks on LCD display. The DCS will display as entered.

2. **Base Unit:** From the drop-down menu, select a base unit to be used for the custom unit relationship.
3. **Base per Custom:** Enter a numeric value that represents the number of base units per one custom unit.

The Rosemount 3051SMV uses the following convention:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}}$$

Example:

**Custom Unit:** kg **Base Unit:** g

Because:

1 kg (Kilogram) = 1000 g (Grams)

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{1000 \cdot \text{g}}{1 \cdot \text{kg}} = 1000$$

The values of **Base per Custom** for common energy units are shown in [Table 2-10](#).

4. Select **Apply**.
5. **Energy Rate Unit:** From the drop-down menu, select the **Custom Unit** that was created in [Step 2](#).

**Example**

**Note**

The **Custom Unit** may not be available as a selection in the **Energy Rate Unit** drop-down menu until the drop-down menu is refreshed. To refresh the drop-down menu, navigate to the **Basic Setup** tab and then return to the **Variables** → **Energy** tab.

**Table 2-10: Common Custom Units - Energy Flow**

| Custom Unit                                | Base Unit | Base per Custom |
|--|-----------|-----------------|
| British thermal unit (BTU) per Day (BTU/D) | Btu/h     | 0.041667        |
| BTU per Minute (BTU/M)                     | Btu/h     | 60              |
| Megajoules per Day (MJ/D)                  | MJ/h      | 0.041667        |
| Megajoules per Minute (MJ/M)               | MJ/h      | 60              |
| Thousands of BTU per Day (KBTUD)           | Btu/h     | 41.6667         |
| Thousands of BTU per Hour (KBTUH)          | Btu/h     | 1000            |

If conversion factor tables or internet search engines are used to determine the **Base per Custom** value, it is important to enter the **Custom Unit** in the **From** field and the **Base Unit** in the **To** Field. An example of this is shown below:

Convert what quantity? 1

| From:                | To:                        |
|----------------------|----------------------------|
| megaelectronvolt     | meter atmosphere           |
| megacalorie [I.T.]   | megaelectronvolt           |
| megacalorie [15° C]  | megacalorie [I.T.]         |
| <b>megajoule/day</b> | <b>megacalorie [15° C]</b> |
| megalerg             | megajoule/hour             |
| megaton [explosive]  | megalerg                   |
| megawatthour         | megaton [explosive]        |
| meter kilogram-force | megawatthour               |
| microjoule           | meter kilogram-force       |
| millijoule           | microjoule                 |
|                      | milli joule                |

Convert

**Result:**  
1 megajoule/day = 0.041667 megajoule/hour

To calculate the **Base per Custom** value for a custom unit not shown in [Table 2-10](#), see one of the following examples:

- Energy conversion example: [Energy conversion example](#)
- Time conversion example: [Time conversion example](#)
- Energy and time conversion example: [Energy and time conversion example](#)

### Energy conversion example

To find the Base per Custom relationship for a custom unit of thousands of BTU per hour (kBtuh) and a base unit of BTU per hour (Btu/h), input the following:

**Custom Unit** = kBtuh

**Base Unit** = Btu/h

Because:

1 kBtu (Thousands of BTU) = 1000 Btu

$$\text{Then: } 1 \text{ kBtuh} = \frac{1 \cdot \text{kBtu}}{1 \cdot \text{h}} \times \frac{1000 \cdot \text{Btu}}{1 \cdot \text{h}} = 1000 \text{ Btu/h}$$


1 kBtuh = 1000 Btu/h

Therefore:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{1000 \cdot \text{Btu/h}}{1 \cdot \text{kBtuh}} = 1000$$



Figure 2-31: Energy Rate Custom Units - Energy Conversion Example



### Time conversion example

To find the **Base per Custom** relationship for a custom unit of standard cubic feet per hour (scf/h) and a **Base Unit** of standard cubic feet per minute (StdCuft/min), input the following:

$$\text{Custom Unit} = \text{scf/h} \quad \text{Base Unit} = \text{StdCuft/min}$$

Because:

$$1 \text{ h (Hour)} = 60 \text{ min (Minutes)}$$


$$\text{Then: } 1 \text{ scf/h} = \frac{1 \cdot \text{scf}}{1 \cdot \text{h}} \times \frac{1 \cdot \text{h}}{60 \cdot \text{min}} = 0.016667 \text{ StdCuft/min}$$

$$1 \text{ scf/h} = 0.016667 \text{ StdCuft/min}$$

Therefore:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{0.016667 \cdot \text{StdCuft/min}}{1 \cdot \text{scf/h}} = 0.016667$$

Figure 2-32: Flow Rate Custom Unit - Time Conversion Example



### Energy and time conversion example

To find the **Base per Custom** relationship for a custom unit of thousands of BTU per day (kBtud) and a base unit of BTU per hour (Btu/h), input the following:

**Custom Unit** = kBtud Base Unit = Btu/h

Because:

1 kBtu (Thousands of BTU)= 1000 Btu and

1 d (Day) = 24 h (Hours)

Then:


$$1 \text{ kBtud} = \frac{1 \cdot \text{kBtu}}{1 \cdot \text{d}} \times \frac{1000 \cdot \text{Btu}}{1 \cdot \text{kBtu}} \times \frac{1 \cdot \text{d}}{24 \cdot \text{h}} = 41.6667 \text{ Btu/h}$$

$$1 \text{ kBtud} = 41.6667 \text{ Btu/h}$$

Therefore:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{41.6667 \cdot \text{Btu/h}}{1 \cdot \text{kBtud}} = 41.6667$$

Figure 2-33: Energy Rate Custom Units - Energy and Time Conversion Example



- Under the Low Flow Cutoff heading, edit the current Minimum DP Value as needed. The unit for this value is the user-selected DP unit. If the measured DP value is less than the minimum DP value, the transmitter will calculate the energy value to be zero.
- The **Upper Sensor Limit**, **Lower Sensor Limit**, and **Minimum Span** can be viewed under the **Energy Rate Sensor Limits** heading.

## 2.6.3


## Totalizer

Mass and energy flow fast keys 1, 4, 1, 3

Fully compensated mass and energy flow feature board only.

The **Totalizer** tab is used to configure the settings associated with the totalizer functionality within the transmitter.

Figure 2-34: Variables → Totalizer Tab



### Procedure

1. To turn the totalizer functionality on or off, select **Start** or **Stop** from the **Mode** drop down menu under the **Totalizer Setup** heading. The totalizer **Units** may also be edited under this heading.
2. Verify the **Totalized Parameter** and the **Maximum Value**. To edit the **Totalized Parameter**, select the **Configure Totalizer** button under the **Totalizer Control** heading.

---

#### Note

When the totalizer reaches its maximum value, it automatically resets to zero and continues totalizing. The default maximum is a value equivalent to 4.29 billion pounds, actual cubic feet, or BTU. To edit the **Maximum Value**, select the **Set Totalizer Maximum** button under the **Totalizer Control** heading.

---

3. To reset the **Totalized Reading** to zero, select the **Reset Totalizer** button under the **Totalizer Control** heading.
4. Under the **Custom Units Setup** heading, the user may configure a **Custom Unit** for the **Totalized Reading**. Custom units allow the totalizer rate to be displayed in units of measure that are not standard in the Rosemount 3051SMV.

---

#### Note

If the totalizer rate is configured as the primary variable and is being output via the 4–20 mA signal, verify the 4–20 mA range (LRV and URV) after completing the custom unit configuration. For more information on verifying the 4–20 mA range, see [Basic device configuration](#).

---

Follow these steps to configure a custom unit:

- a) **Custom Unit:** Enter the desired custom unit label to be displayed for the **Totalized Reading**. Up to five characters including letters, numbers, and symbols can be entered in the custom unit field.

---

#### Note

It is recommended that the **Custom Unit** be entered in upper case letters. If lower case letters are entered, the LCD display will show upper case letters. Additionally, the following special characters are recognized by the LCD display: hyphens ("-"), percent symbols ("%"), asterisks ("\*"), forward slashes ("/") and spaces. Any other character entered for the **Custom Unit** will be displayed as an asterisk ("\*") on the LCD display. The following warning will be returned indicating these changes: Custom Unit contains characters that will display in upper case or asterisks on LCD display. The DCS will display as entered.

---

- b) **Base Unit:** From the drop-down menu, select a base unit to be used for the custom unit relationship.
- c) **Base per Custom:** Enter a numeric value that represents the number of base units per one custom unit.

The Rosemount 3051SMV uses the following convention: **Base per Custom** = 
$$\frac{\text{Number of Base Units}}{1 \text{ Custom Unit}}$$

Example:

**Custom Unit:** kg

**Base Unit:** g

Because:

1 kg (Kilogram) = 1000 g (Grams)

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{1000 \cdot \text{g}}{1 \cdot \text{kg}} = 1000$$

The values of **Base per Custom** for common totalizer units are shown in [Table 2-11](#).

- d) Select **Apply**.
- e) **Totalizer Unit**: From the drop-down menu, select the custom unit that was created in [4.b](#).

**Note**

The custom unit may not be available as a selection in the **Totalizer Unit** drop-down menu until the drop-down menu is refreshed. To refresh the drop-down menu, navigate to the **Basic Setup** tab and then return to the **Variables** → **Totalizer** tab.

**Table 2-11: Common Custom Units - Totalizer**

| Custom Unit                               | Base Unit | Base per Custom |
|---|-----------|-----------------|
| Millions of Normal Cubic Meters (MMNCM)   | NmlCum    | 1000000         |
| Millions of Standard Cubic Feet (MMSCF)   | StdCuft   | 1000000         |
| Millions of Standard Cubic Meters (MMSCM) | StdCum    | 1000000         |
| Thousands of Metric Tons (KMTON)          | MetTon    | 1000            |
| Thousands of Normal Cubic Meters (KNCM)   | NmlCum    | 1000            |
| Thousands of Short Tons (KSTON)           | STon      | 1000            |
| Thousands of Standard Cubic Feet (KSCF)   | StdCuft   | 1000            |
| Thousands of Standard Cubic Meters (KSCM) | StdCum    | 1000            |

If conversion factor tables or internet search engines are used to determine the **Base per Custom** value, it is important to enter the **Custom Unit** in the **From** field and the **Base Unit** in the **To** Field.

To calculate the **Base per Custom** value for a custom unit not shown in [Table 2-9](#), see [Totalizer conversion example](#).

**Totalizer conversion example**

To find the **Base per Custom** relationship for a custom unit of millions of standard cubic feet (mmscf) and a base unit of standard cubic feet (StdCuft), input the following:

**Custom Unit** = mmscf

**Base Unit** = StdCuft


Because:

1 mmscf (millions of standard cubic feet) = 1000000 StdCuft (Standard Cubic Feet)

Therefore:

$$\text{Base per Custom} = \frac{\text{Number of Base Units}}{1 \text{ Custom Unit}} = \frac{1000000 \cdot \text{StdCuft}}{1 \cdot \text{mmscf}} = 1000000$$

Figure 2-35: Totalizer Custom Units - Example



## 2.6.4

## Differential pressure


Mass and energy flow fast keys 1, 4, 1, 4

Direct process variable output fast keys 1, 4, 1, 1

### Note

For differential pressure sensor calibration, see [Differential pressure sensor calibration](#).

Figure 2-36: Variables → Differential Pressure Tab



- Under the **Differential Pressure Setup** heading, edit the **Unit** and **Damping** values as needed.
- The **Upper Sensor Limit**, **Lower Sensor Limit**, and **Minimum Span** can be viewed under the **Differential Pressure Sensor Limits** heading.

## 2.6.5 Static pressure


**Mass and energy flow fast keys** 1, 4, 1, 5

**Direct process variable output fast keys** 1, 4, 1, 2

### Note

For static pressure sensor calibration, see [Static Pressure Calibration](#).

Figure 2-37: Variables → Static Pressure Tab



- Under the **Static Pressure Setup** heading, edit the **Absolute Unit** and **Gage Unit** as needed. The **Damping** may also be edited.

### Note

The transmitter may be equipped with either an absolute or gage static pressure sensor type depending on specified model code. The type of static pressure sensor equipped in the transmitter can be determined by referring to the **Static Pressure Sensor Type** heading. The static pressure type not being measured is a calculated value using the atmospheric pressure value as specified under the **User Defined Atmospheric Pressure** heading.

- The **Upper Sensor Limit**, **Lower Sensor Limit**, and **Minimum Span** for the absolute and gage static pressure can be viewed under the **Absolute Pressure Sensor Limits** and **Gage Pressure Sensor Limits** headings.

## 2.6.6 Process temperature


**Mass and energy flow fast keys** 1, 4, 1, 6

**Direct process variable output fast keys** 1, 4, 1, 3

### Note

For process temperature sensor calibration, see [Process temperature sensor calibration](#) . If a transmitter was ordered with Fixed Process Temperature Only, the Fixed Temperature Value and Units can be edited on the **Fixed Temperature** tab.

Figure 2-38: Variables → Process Temperature Tab



- Under the **Process Temperature Setup** heading, edit the **Unit** and **Damping** value as needed.
- Select the **Temperature Mode** under the **Process Temperature Setup** heading. See [Table 2-12](#).

Table 2-12: Temperature Modes

| Temperature mode | Description  |
|------------------|--|
| <b>Normal</b>    | The transmitter will only use the actual measured <b>Process Temperature</b> value. If the temperature sensor fails, the transmitter will put the analog signal into <b>Alarm</b> .                    |
| <b>Backup</b>    | The transmitter will use the actual measured <b>Process Temperature</b> value. If the temperature sensor fails, the transmitter will use the value shown in the <b>Fixed/Backup Temperature</b> field. |
| <b>Fixed</b>     | The transmitter will always use the temperature value shown in the <b>Fixed/Backup Temperature</b> field.  |



**Note**

**Process Temperature Mode Setup** only applies to transmitters with fully compensated mass and energy flow feature board.

- The **Upper Sensor Limit**, **Lower Sensor Limit**, and **Minimum Span** can be viewed under the **Process Temperature Sensor Limits** heading. The **Upper Sensor Limit** and **Lower Sensor Limit** may be edited as needed.

The Rosemount 3051SMV accepts Callendar-Van Dusen constants from a calibrated RTD schedule and generates a special custom curve to match that specific sensor Resistance vs. Temperature performance. Matching the specific sensor curve with the transmitter configuration enhances the temperature measurement accuracy.

Under the **Sensor Matching** heading, the Callendar-Van Dusen constants  $R_0$ , A, B, and C can be viewed. If the Callendar-Van Dusen constants are known for the user's specific Pt 100 RTD sensor, the constants  $R_0$ , A, B, and C may be edited by selecting the **Callendar-Van Dusen Setup** button and following the on-screen prompts. The user may also view the  $\alpha$ ,  $\beta$ , and  $\delta$  coefficients by selecting the **View Alpha Beta Delta** button. To reset the transmitter to the IEC 751 Defaults, select the **Reset to IEC 751 Defaults** button.


## 2.6.7 Module temperature

**Mass and energy flow fast keys** 1, 4, 1, 7

**Direct process variable output fast keys** 1, 4, 1, 4

The sensor module temperature variable is the measured temperature of the sensors and electronics within the SuperModule™ assembly. The module temperature can be used to control heat tracing or diagnose device overheating.

**Figure 2-39: Variables → Module Temperature Tab**



- Under the **Module Temperature Setup** heading, edit the **Unit** as needed.
- The **Upper Sensor Limit** and **Lower Sensor Limit** can be viewed under the **Module Temperature Sensor Limits** heading.

## 2.6.8 Analog output


**Mass and energy flow fast keys** 1, 4, 3, 2

**Direct process variable output fast keys** 1, 4, 3, 2

### Note

For Analog calibration, see [Analog calibration](#).

**Figure 2-40: Variables → Analog Output Tab**



### Procedure

1. Select the **Primary Variable** under the **Analog Output Setup** heading. The **Upper Range Value** and **Lower Range Value** may also be edited under this heading.
2. Verify the **Upper Sensor Limit**, **Lower Sensor Limit**, and **Minimum Span** under the **Primary Variable Sensor Limits** heading.

### Transfer function (direct process variable output feature board only)

The Rosemount 3051SMV with direct process variable output feature board has two analog output settings: **Linear** and **Square Root**.


Activate the **Square Root** output option to make analog output proportional to flow. As input approaches zero, the Rosemount 3051SMV automatically switches to **Linear** output in order to ensure a smooth, stable output near zero (see [Figure 2-41](#)).

From 0 to 0.6 percent of the ranged pressure input, the slope of the curve is unity ( $y = x$ ). This allows accurate calibration near zero. Greater slopes would cause large changes in output (for small changes at input). From 0.6 to 0.8 percent, curve slope equals 41.72 ( $y = 41.72x$ ) to achieve continuous transition from linear to square root at the transition point.

### Note

Do not set both the analog output of the device and the control system to **Square Root**.

Figure 2-41: Square Root output transition point



- A. Full scale output (mA dc)
- B. Full scale flow (percent)
- C. Square root curve
- D. Transition point
- E. Slope
- F. Percent pressure input
- G. Transition point
- H. Linear section

Figure 2-41 only applies to the **Square Root** output for the Rosemount 3051SMV with the direct process variable output feature board.

**Note**

For a flow turndown of greater than 10:1, it is not recommended to perform a square root transfer function in the transmitter. Instead, perform the square root transfer function in the control system.

## 2.7 Menu trees and communication device fast keys


Based on the configuration ordered, some measurements (such as static pressure, process temperature) and/or calculation types (i.e. mass, volumetric, and energy flow) may not be available for all fluid types. Available measurements and/or calculation types are determined by the multivariable type and measurement type codes ordered. See the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#) for more information.

The menu trees and Field Communicator Fast Keys in this section are shown for the following model codes:

- Multivariable type M (fully compensated mass and energy flow) with measurement type 1 (**Differential Pressure, Static Pressure, and Process Temp.**)
- Multivariable type P (direct process variable output) with measurement type 1 (**Differential Pressure, Static Pressure, and Process Temp.**)

The menu trees and communication device Fast Keys for other model codes will vary.

Figure 2-42: Menu Tree for Fully Compensated Mass and Energy Flow








Figure 2-43: Menu Tree for Direct Process Variable Output





## 2.7.1 Communication device Fast Keys

Use Rosemount 3051SMV Engineering Assistant or any HART-compliant master to communicate with and verify configuration of the Rosemount 3051SMV.

Table 2-13 shows the communication device Fast Keys for the fully compensated mass and energy flow. Table 2-14 shows the Fast Keys for the direct process variable output.

A check (✓) indicates the basic configuration parameters. At a minimum, these parameters should be verified as part of the configuration and startup procedure.

**Table 2-13: Fast Keys for Fully Compensated Mass and Energy Flow Output**

|     | Function  | Fast Key sequence |
|-----|---|-------------------|
| N/A | <b>Absolute Pressure Reading and Status</b>     | 1, 4, 2, 1, 5     |
| N/A | <b>Absolute Pressure Sensor Limits</b>          | 1, 4, 1, 5, 8     |
| N/A | <b>Absolute Pressure Units</b>                  | 1, 3, 3, 5        |
| N/A | <b>Alarm and Saturation Level Configuration</b> | 1, 4, 2, 6, 6     |



**Table 2-13: Fast Keys for Fully Compensated Mass and Energy Flow Output**  
*(continued)*

|     | Function   | Fast Key sequence |
|-----|--|-------------------|
| N/A | <b>Alarm and Saturation Levels</b>               | 1, 4, 2, 6        |
| N/A | <b>Analog Output Trim Options</b>                | 1, 2, 5, 2        |
| N/A | <b>Burst Mode Setup</b>                          | 1, 4, 3, 3, 3     |
| N/A | <b>Burst Mode Options</b>                        | 1, 4, 3, 3, 4     |
| N/A | <b>Callendar-van Dusen Sensor Matching</b>       | 1, 2, 5, 5, 4     |
| N/A | <b>Configure Fixed Variables</b>                 | 1, 2, 4           |
| N/A | <b>Damping</b>                                   | 1, 3, 7           |
| N/A | <b>Diaphragm Seals Information</b>               | 1, 4, 4, 5        |
| ✓   | <b>Differential Pressure Low Flow Cutoff</b>     | 1, 4, 1, 1, 6     |
| N/A | <b>Differential Pressure Reading and Status</b>  | 1, 4, 2, 1, 4     |
| N/A | <b>Differential Pressure Sensor Trim Options</b> | 1, 2, 5, 3        |
| ✓   | <b>Differential Pressure Zero Trim</b>           | 1, 2, 5, 3, 1     |
| N/A | <b>Differential Pressure Units</b>               | 1, 3, 3, 4        |
| N/A | <b>Energy Rate Units</b>                         | 1, 3, 3, 2        |
| N/A | <b>Energy Reading and Status</b>                 | 1, 4, 2, 1, 2     |
| N/A | <b>Equipped Sensors</b>                          | 1, 4, 4, 4        |
| N/A | <b>Field Device Information</b>                  | 1, 4, 4, 1        |
| N/A | <b>Flow Calculation Type</b>                     | 1, 4, 1, 1, 2     |
| ✓   | <b>Flow Rate Units</b>                           | 1, 3, 3, 1        |
| N/A | <b>Flow Reading and Status</b>                   | 1, 4, 2, 1, 1     |
| N/A | <b>Gage Pressure Reading and Status</b>          | 1, 4, 2, 1, 6     |
| N/A | <b>Gage Pressure Sensor Limits</b>               | 1, 4, 1, 5, 9     |
| N/A | <b>Gage Pressure Units</b>                       | 1, 3, 3, 6        |
| N/A | <b>LCD Display Configuration</b>                 | 1, 3, 8           |
| N/A | <b>Loop Test</b>                                 | 1, 2, 2           |
| N/A | <b>Module Temperature Reading and Status</b>     | 1, 4, 2, 1, 8     |
| N/A | <b>Module Temperature Units</b>                  | 1, 3, 3, 8        |
| N/A | <b>Poll Address</b>                              | 1, 4, 3, 3, 1     |
| N/A | <b>Process Temperature Reading and Status</b>    | 1, 4, 2, 1, 7     |
| ✓   | <b>Process Temperature Sensor Mode</b>           | 1, 4, 1, 6, 8     |

**Table 2-13: Fast Keys for Fully Compensated Mass and Energy Flow Output**  
*(continued)*

|     | Function   | Fast Key sequence |
|-----|--|-------------------|
| N/A | Process Temperature Sensor Trim Options                      | 1, 2, 5, 5        |
| N/A | Process Temperature Unit                                     | 1, 3, 3, 7        |
| ✓   | Ranging the Analog Output                                    | 1, 2, 5, 1        |
| N/A | Recall Factory Trim Settings                                 | 1, 2, 5, 2, 3     |
| N/A | Sensor Information   | 1, 4, 4, 2        |
| ✓   | Static Pressure Sensor Lower Trim (Absolute Pressure Sensor) | 1, 2, 5, 4, 2     |
| N/A | Static Pressure Sensor Trim Options                          | 1, 2, 5, 4        |
| ✓   | Static Pressure Sensor Zero Trim (Gage Pressure Sensor)      | 1, 2, 5, 4, 1     |
| ✓   | Status   | 1, 2, 1           |
| ✓   | Tag  | 1, 3, 1           |
| N/A | Test Flow Calculation  | 1, 2, 3           |
| N/A | Totalizer Configuration                                      | 1, 4, 1, 3        |
| N/A | Totalizer Reading and Status                                 | 1, 4, 2, 1, 3     |
| N/A | Totalizer Units  | 1, 3, 3, 3        |
| N/A | Variable Mapping   | 1, 4, 3, 4        |
| N/A | Write Protect  | 1, 3, 5, 4        |

**Table 2-14: Fast Keys for Direct Process Variable Measurement**

|   | Function                                 | Fast Key sequence |
|---|--|-------------------|
|   | Absolute Pressure Reading and Status     | 1, 4, 2, 1, 2     |
|   | Absolute Pressure Sensor Limits          | 1, 4, 1, 2, 8     |
| ✓ | Absolute Pressure Units                  | 1, 3, 3, 2        |
|   | Alarm and Saturation Level Configuration | 1, 4, 2, 6, 6     |
|   | Alarm and Saturation Levels              | 1, 4, 2, 6        |
|   | Analog Output Trim Options               | 1, 2, 4, 2        |
|   | Burst Mode Setup                         | 1, 4, 3, 3, 3     |
|   | Burst Mode Options                       | 1, 4, 3, 3, 4     |
|   | Callendar-van Dusen Sensor Matching      | 1, 2, 4, 5, 4     |
|   | Damping                                  | 1, 3, 7           |
|   | Diaphragm Seals Information              | 1, 4, 4, 4        |

**Table 2-14: Fast Keys for Direct Process Variable Measurement (continued)**

|   | Function                                      | Fast Key sequence |
|---|---|-------------------|
|   | Differential Pressure Reading and Status      | 1, 4, 2, 1, 1     |
|   | Differential Pressure Sensor Trim Options     | 1, 2, 4, 3        |
| ✓ | Differential Pressure Zero Trim               | 1, 2, 4, 3, 1     |
| ✓ | Differential Pressure Units                   | 1, 3, 3, 1        |
|   | Equipped Sensors                              | 1, 4, 4, 3        |
|   | Field Device Information                      | 1, 4, 4, 1        |
|   | Gage Pressure Reading and Status              | 1, 4, 2, 1, 3     |
|   | Gage Pressure Sensor Limits                   | 1, 4, 1, 2, 9     |
| ✓ | Gage Pressure Units                           | 1, 3, 3, 3        |
|   | LCD Display Configuration                     | 1, 3, 8           |
|   | Loop Test                                     | 1, 2, 2           |
|   | Module Temperature Reading and Status         | 1, 4, 2, 1, 5     |
|   | Module Temperature Units                      | 1, 3, 3, 5        |
|   | Poll Address                                  | 1, 4, 3, 3, 1     |
|   | Process Temperature Reading and Status        | 1, 4, 2, 1, 4     |
|   | Process Temperature Sensor Trim Options       | 1, 2, 4, 5        |
| ✓ | Process Temperature Unit                      | 1, 3, 3, 4        |
| ✓ | Ranging the Analog Output                     | 1, 2, 4, 1        |
|   | Recall Factory Trim Settings                  | 1, 2, 4, 2, 3     |
|   | Sensor Information                            | 1, 4, 4, 2        |
| ✓ | Static Pressure Sensor Lower Trim (AP Sensor) | 1, 2, 4, 4, 2     |
|   | Static Pressure Sensor Trim Options           | 1, 2, 4, 4        |
| ✓ | Static Pressure Sensor Zero Trim (GP Sensor)  | 1, 2, 4, 4, 1     |
| ✓ | Status  | 1, 2, 1           |
| ✓ | Tag   | 1, 3, 1           |
| ✓ | Transfer Function                             | 1, 3, 6           |
|   | Variable Mapping                              | 1, 4, 3, 4        |
|   | Write Protect                                 | 1, 3, 5, 4        |



## 3 Installation

### 3.1 Overview

This section contains information that covers installation considerations for Rosemount 3051S MultiVariable™ Transmitter (Rosemount 3051SMV).

The Rosemount 3051SMV [Quick Start Guide](#) is shipped with every transmitter to describe basic installation, wiring, configuration, and startup procedures. Dimensional drawings for each Rosemount 3051SMV type and mounting configuration are included in the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#).

### 3.2 Installation considerations

Measurement accuracy depends upon proper installation of the transmitter and impulse piping. Mount the transmitter close to the process and use a minimum of piping to achieve best accuracy. Keep in mind the need for easy access, personnel safety, practical field calibration, and a suitable transmitter environment. Install the transmitter to minimize vibration, shock, and temperature fluctuation.

---

#### Note

Install the enclosed pipe plug in the unused conduit opening if optional process temperature input is not used. For proper straight and tapered thread engagement requirements, see the appropriate approvals drawings on the [Rosemount 3051S MultiVariable Transmitter page](#).

For material compatibility considerations, refer to [Material Selection and Compatibility Considerations for Rosemount Pressure Transmitters Technical Note](#)

---

#### 3.2.1 Mechanical considerations

##### Steam service

For steam service or for applications with process temperatures greater than the limits of the transmitter, do not blow down impulse piping through the transmitter. Flush lines with the blocking valves closed and refill lines with water before resuming measurement.

##### Side mounted

When the transmitter is mounted on its side, position the Coplanar™ flange to ensure proper venting or draining.

Keep drain/vent connections on the bottom for gas service and on the top for liquid service when mounting the flange.

##### Related information

[Install bolts](#)

#### 3.2.2 Environmental considerations

Access requirements and cover installation can help optimize transmitter performance.

Mount the transmitter to minimize ambient temperature changes, vibration, and mechanical shock and to avoid external contact with corrosive materials.

## 3.3 Installation procedures

### 3.3.1 Configure security (write protect)

Changes to the transmitter configuration data can be prevented with the security (**write protect**) switch located on the feature board.

See [Figure 3-1](#) for the location of the switch. Position the switch in the **ON** position to prevent accidental or deliberate change of configuration data.

If the transmitter write protection switch is in the **ON** position, the transmitter will not accept any “writes” to its memory. Configuration changes, such as digital trim and reranging, cannot take place when the transmitter security is **On**.

To reposition the switches:

#### Prerequisites


#### **⚠ WARNING**

Do not remove the transmitter covers in explosive atmospheres when the circuit is live.

#### Procedure

1. If the transmitter is live, set the loop to **Manual** and remove power.
2. Remove the housing cover opposite the field terminal side of the housing.
3. To reposition the switches as desired, slide the **Security** and **Alarm** switches into the preferred position using a small screwdriver. See [Figure 3-1](#).

**Figure 3-1: Switch Configuration**



- A. Feature board
- B. **Security**
- C. **Alarm**

4. Re-install the transmitter cover.

#### **⚠ WARNING**

Transmitter covers must be fully engaged so that metal contacts metal in order to meet flameproof/explosion-proof requirements.

### 3.3.2 Configure alarm direction

The transmitter alarm direction is set by repositioning the **Alarm** switch.

Position the switch in the **High (HI)** position for fail high and in the **Low (LO)** position for fail low.

### 3.3.3 Mounting considerations

For dimensional drawing information refer to the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#).

#### Rotate housing

Rotate housing to improve access to wiring or to better view the LCD display (if ordered).

To rotate the housing:

##### Procedure

1. Loosen the housing set screw.
2. Turn the housing up to 180° to the left or right of its original (as shipped) position.


#### NOTICE

Over rotation may sever the electrical connection between the sensor module and the electronics feature board.

Do not rotate the housing more than 180° from its original position without first performing a disassembly procedure (see [Disassembly considerations](#)).

3. Retighten the housing rotation set screw.

**Figure 3-2: Housing**



- A. Feature board
- B. 3/32-in. housing rotation set screw

#### LCD display rotation

In addition to rotating the housing, the optional LCD display on the primary sensor can be rotated in 90° increments by squeezing the two tabs, pulling out the display, rotating, and snapping the display back into place.

---

**Note**

If the LCD display pins are inadvertently removed from the electronics feature board, re-insert the pins before snapping the LCD display back into place.

---

**Field terminal side of housing**

Mount the transmitter so the terminal side is accessible. Clearance of 0.75 in. (19 mm) is required for cover removal. Use a conduit plug in the unused conduit opening if the optional **Process Temperature** Input is not installed.

**Feature board side of housing**

Provide 0.75-in. (19 mm) of clearance for units without an LCD display. Three inches of clearance is required for cover removal if an LCD display is installed.

**Cover installation****NOTICE**

Always ensure a proper seal by installing the housing covers so that metal contacts metal in order to prevent performance degradation due to environmental effects.

---

For replacement cover O-rings, use Rosemount O-rings (part number 03151-9040-0001).

**Conduit entry threads**

For NEMA® 4X, IP66, and IP68 requirements, use thread seal (PTFE) tape or paste on male threads to provide a watertight seal.

**Install cover jam screw**

For transmitter housings shipped with a cover jam screw, as shown in [Figure 3-3](#), install the screw once the transmitter has been wired and powered up.

The cover jam screw is intended to prevent the removal of the transmitter cover in Flameproof environments without the use of tools.

**Procedure**

1. Verify the cover jam screw is completely threaded into the housing.
2. Install the transmitter housing covers and verify that metal contacts metal in order to meet Flameproof/explosion-proof requirements.
3. Using an M4 hex wrench, turn the jam screw counterclockwise until it contacts the transmitter cover.
4. Turn the jam screw an additional turn counterclockwise to secure the cover.

**NOTICE**


Applying excessive torque may strip the threads.

---

5. Verify the covers cannot be removed.



Figure 3-3: Cover jam screw



A. Cover jam screw (one per side)

### Process flange orientation

Mount the process flanges with sufficient clearance for process connections.

#### **⚠ WARNING**


For safety reasons, place the drain/vent valves so the process fluid is directed away from possible human contact when the vents are used.

In addition, consider the need for a testing or calibration input.

### 3.3.4 Mount the transmitter

Figure 3-4 illustrates a typical transmitter installation site measuring dry gas with an orifice plate.

Figure 3-4: Typical transmitter installation site



- A. Transmitter
- B. RTD cable
- C. Pt 100 RTD sensor
- D. Process connections
- E. Flow

## Mounting brackets

You can mount the transmitter to a 2-in. (51 mm) pipe or to a panel using an optional mounting bracket.

Use the B4 Bracket stainless steel (SST) option with the Coplanar™ flange process connection. [Table 3-1](#) shows bracket dimensions and mounting configurations. When installing the transmitter to one of the optional mounting brackets, torque the bolts to 125 in.-lb. (0.9 N-m).

**Table 3-1: Mounting Brackets**


| Options | Description                     | Mounting type    | Bracket material          | Bolt material |
|---------|---------------------------------|------------------|---------------------------|---------------|
| B4      | Coplanar flange bracket         | 2-in. pipe/panel | SST                       | SST           |
| B1      | Traditional flange bracket      | 2-in. pipe       | Painted CS (Carbon steel) | CS            |
| B2      | Traditional flange bracket      | Panel            | Painted CS                | CS            |
| B3      | Traditional flange flat bracket | 2-in. pipe       | Painted CS                | CS            |
| B7      | Traditional flange bracket      | 2-in. pipe       | Painted CS                | SST           |
| B8      | Traditional flange bracket      | Panel            | Painted CS                | SST           |
| B9      | Traditional flange flat bracket | 2-in. pipe       | Painted CS                | SST           |
| BA      | Traditional flange bracket      | 2-in. pipe       | SST                       | SST           |
| BC      | Traditional flange flat bracket | 2-in. pipe       | SST                       | SST           |

## Flange bolts

Emerson can ship the transmitter with a Coplanar™ flange or a traditional flange installed with four 1.75-in. (44 mm) flange bolts.

Stainless steel bolts supplied by Emerson are coated with a lubricant to ease installation. Carbon steel bolts do not require lubrication. Do not apply additional lubricant when installing either type of bolt. Bolts supplied by Emerson are identified by their head markings.

**Figure 3-5: Head Markings**



- A. Carbon steel (CS) head markings
- B. Stainless steel (SST) head markings
- C. Alloy K-500 head marking

**Note**

The last digit in the F593\_head marking may be any letter between A and M.

**Install bolts**

When installing the transmitter to a mounting bracket, use only supplied or Emerson-provided bolts and torque them in a crossing pattern to 125 in.-lb., initially finger-tightening them before final torquing.

**NOTICE**

Only use bolts supplied with the transmitter or provided by Emerson as spare parts. When installing the transmitter to one of the optional mounting brackets, torque the bolts to 125 in.-lb. (0.9 N-m).

**Procedure**



1. Finger-tighten the bolts.
2. Torque the bolts to the initial torque value using a crossing pattern.
3. Torque the bolts to the final torque value using the same crossing pattern.

Torque values for the flange and manifold adapter bolts are as follows:

**Table 3-2: Bolt installation torque values**



| Bolt material                           | Initial torque value | Final torque value  |
|---|----------------------|---------------------|
| Carbon steel (CS)-ASTM-A449 Standard    | 300 in.-lb (34 N-m)  | 650 in.-lb (73 N-m) |
| 316 stainless steel (SST)—Option L4     | 150 in.-lb (17 N-m)  | 300 in.-lb (34 N-m) |
| ASTM-A-193-B7M—Option L5                | 300 in.-lb (34 N-m)  | 650 in.-lb (73 N-m) |
| ASTM-A-193 Class 2, Grade B8M—Option L8 | 150 in.-lb (17 N-m)  | 300 in.-lb (34 N-m) |

**Table 3-3: Traditional flange bolt configurations**

| Differential transmitter   | Gauge transmitter   |
|--|---|
|  <p>1.75 (44) x 4</p> |  <p>1.75 (44) x 4<br/>1.50 (38) x 2</p> |

- a. Drain/vent
- b. Plug

**Table 3-4: Mounting bolts and bolt configurations for coplanar flange**

| Transmitter with flange bolts  | Transmitter with flange adapters and flange/adaptor bolts   |
|--|---|
|  <p>1.75 (44) x 4</p> | <p>Transmitter with flange adapters and flange/adaptor bolts</p>  <p>2.88 (73) x 4</p> |

**Table 3-5: Bolts**

| Description           | Size             |
|-----------------------|------------------|
| Flange Bolts          | 1.75 in. (44 mm) |
| Flange/Adapter Bolts  | 2.88 in. (73 mm) |
| Manifold/Flange Bolts | 2.25 in. (57 mm) |

## Mounting requirements

Impulse piping configurations depend on specific measurement conditions.

### Liquid flow measurement

- Place taps to the side of the line to prevent sediment deposits on the process isolators.
- Mount the transmitter beside or below the taps so gases vent into the process line.
- Mount drain/vent valve upward to allow gases to vent.

### Gas flow measurement

- Place taps in the top or side of the line.
- Mount the transmitter beside or above the taps so to drain liquid into the process line.


### Steam flow measurement

- Place taps to the side of the line.
- Mount the transmitter below the taps to ensure that impulse piping will remain filled with condensate.
- In steam service above +250 °F (+121 °C), fill impulse lines with water to prevent steam from contacting the transmitter directly and to ensure accurate measurement startup.

## NOTICE


For steam or other elevated temperature services, it is important that temperatures at the process connection do not exceed the transmitter's process temperature limits. See Temperature Limits in the [2051 Pressure Transmitter Product Data Sheet](#) for details.

Figure 3-6: Liquid installation example



A. Flow


Figure 3-7: Gas installation example



A. Flow



Figure 3-8: Steam service installation example



A. Flow

### 3.3.5 Install adapters to flange

The process connection size on a transmitter flange is ¼-18-in. NPT.

Flange adapters with a ¼-18 NPT to ½-14 NPT connection are available with the D2 option. Use a plant-approved lubricant or sealant when making the process connections.

The process connections on a transmitter flange are 2½ in. (54 mm) centers to allow direct mounting to a three or five-valve manifold. Rotate one or both of the flange adapters to attain connection centers of 2 in. (51 mm), 1½ in. (54 mm) or 2¼ in. (57 mm).


Install and tighten all four flange bolts before applying pressure to avoid leakage.

When properly installed, the flange bolts will protrude through the top of the SuperModule™ isolator plate. See [Figure 3-9](#).

#### NOTICE

Do not attempt to loosen or remove the flange bolts while the transmitter is in service.

**Figure 3-9: SuperModule isolator plate**



- A. Bolt
- B. SuperModule isolator plate
- C. Coplanar flange
- D. Flange adapters

To install adapters to a Coplanar™ flange:

#### Procedure

1. Remove the flange bolts.
2. Leaving the flange in place, move the adapters into position with the O-rings installed.
3. Attach the adapters and the Coplanar flange to the transmitter SuperModule assembly using the longer of the bolts supplied.
4. Tighten the bolts.  
Refer to [Table 1](#) for torque specifications.

Refer to the correct part numbers of the flange adapters and O-rings designed for the transmitter. Each style of flange adapter requires a unique O-ring.

#### **▲ WARNING**

Use only the O-rings included with the flange adapter for the transmitter.

5. When removing flanges or adapters, visually inspect the PTFE O-rings. Replace them if there are any signs of damage such as nicks or cuts. If replacing O-rings, re-torque the flange bolts after installation to compensate for seating of the PTFE O-ring.

### O-rings

The two styles of Rosemount flange adapters (Rosemount 3051/2051/2024/3095) each require a unique O-ring (see [Figure 3-10](#)). Use only the O-ring designed for the corresponding flange adapter.


## ⚠ WARNING

Failure to install proper flange adapter O-rings may cause process leaks, which can result in death or serious injury.

The two flange adapters are distinguished by unique O-ring grooves. Only use the O-ring that is designed for its specific flange adapter, as shown in [Figure 3-10](#). When compressed, PTFE O-rings tend to cold flow, which aids in their sealing capabilities.

**Figure 3-10: O-rings**

ROSEMOUNT 3051S/3051/2051/3001/3095/2024



- A. Flange adapter
- B. O-ring
- C. PTFE based
- D. Elastomer

## NOTICE

Replace PTFE O-rings if you remove the flange adapter.

## Impulse piping considerations

The piping between the process and the transmitter must accurately transfer the pressure to obtain accurate measurements. There are many possible sources of error: pressure transfer, leaks, friction loss (particularly if purging is used), trapped gas in a liquid line, liquid in a gas line, density variations between the legs, and plugged impulse piping.

The best location for the transmitter in relation to the process pipe depends on the process itself. Use the following guidelines to determine transmitter location and placement of impulse piping:

- Keep impulse piping as short as possible.
- For liquid service, slope the impulse piping at least 1 in. per ft. (8 cm per m) upward from the transmitter toward the process connection.
- For gas service, slope the impulse piping at least 1 in. per ft. (8 cm per m) downward from the transmitter toward the process connection.
- Avoid high points in liquid lines and low points in gas lines.
- Make sure both impulse legs are the same temperature.
- Use impulse piping large enough to avoid friction effects and blockage.
- Vent all gas from liquid piping legs.
- When using a sealing fluid, fill both piping legs to the same level.

- When purging, make the purge connection close to the process taps and purge through equal lengths of the same size pipe. Avoid purging through the transmitter.
- Keep corrosive or hot, above 250 °F (121 °C), process material out of direct contact with the SuperModule process connection and flanges.
- Prevent sediment deposits in the impulse piping.
- Keep the liquid head balanced on both legs of the impulse piping.

## NOTICE

Take necessary steps to prevent process fluid from freezing within the process flange to avoid damage to the transmitter.

### Note

Verify transmitter zero point after installation.

## 3.3.6 Connect wiring and power up


Emerson recommends using twisted pair wiring. To ensure proper communication, use 24 to 14 AWG wire and do not exceed 5000 ft. (1500 m).

## NOTICE


Proper electrical installation is necessary to prevent errors due to improper grounding and electrical noise. Emerson recommends shielded wiring is recommended for environments with high electromagnetic interference (EMI)/radio frequency interference (RFI) levels. Shielded wiring is required in order to comply with NAMUR requirements.

**Figure 3-11: Terminal blocks**

Without optional process temperature connection



With optional process temperature connection



## Procedure

1. Remove the cover on the field terminals side of the housing.

2. Connect the positive lead to the **PWR/COMM +** terminal, and the negative lead to the **PWR/COMM -** terminal.

### NOTICE

Power could damage the test diode in the test connection.

Do not connect the power across the test terminals.

3. If the optional process temperature input is not installed, plug and seal the unused conduit connection.

If the optional process temperature input is being utilized, see [Install optional process temperature input \(Pt 100 RTD sensor\)](#) for more information.

### ⚠ WARNING


When the enclosed pipe plug is utilized in the conduit opening, it must be installed with a minimum engagement of five threads in order to comply with flameproof/explosion-proof requirements.

4. If applicable, install wiring with a drip loop. Arrange the drip loop so the bottom is lower than the conduit connections and the transmitter housing.
5. Reinstall the housing cover and tighten so that metal contacts metal to meet flameproof/explosion-proof requirements.

### Example

Figure 3-12 shows the wiring connections necessary to power a Rosemount 3051SMV and enable communications with a communication device.

**Figure 3-12: Transmitter Wiring**



A. Power supply

### ⚠ WARNING

Installation of the transient protection terminal block does not provide transient protection unless the Rosemount 3051SMV housing is properly grounded.

See [Grounding](#) for more information.

## Install optional process temperature input (Pt 100 RTD sensor)

Use only ATEX/IECEX Flameproof cables (Temperature Input Code C30, C32, C33, or C34) to meet ATEX/IECEX Flameproof certification.

### Procedure

1. Mount the Pt 100 RTD sensor in the appropriate location.

2. **Note**


Use shielded 4-wire cable for the process temperature connection.

Connect the RTD cable to the transmitter by inserting the cable wires through the unused housing conduit and connect to the four screws on the transmitter terminal block.

Use an appropriate cable gland to seal the conduit opening around the cable.

3. Connect the RTD cable shield wire to the ground lug in the housing.

Figure 3-13: Transmitter RTD wiring connection



- A. Pt 100 RTD sensor
- B. RTD cable assembly wires
- C. Ground lug

### 3-wire RTD

A 4-wire Pt 100 RTD is required to maintain published performance specifications.

You may use a 3-wire Pt 100 RTD with degraded performance. If connecting to a three-wire RTD, use a four-wire cable to connect the transmitter terminal block to the RTD connection head. Within the RTD connection head, connect two of the same colored wires from the transmitter to the single colored wire of the RTD sensor.

## Surges/transients

### NOTICE

The transmitter will withstand electrical transients of the energy level usually encountered in static discharges or induced switching transients. However, high-energy transients, such as those induced in wiring from nearby lightning strikes, can damage the transmitter.

### Optional transient protection terminal block

You can order the transient protection terminal block as an installed option (Option Code T1 in the transmitter model number) or as a spare part to retrofit existing 3051S Transmitters in the field. A lightning bolt symbol on a terminal block identifies it as having transient protection.

### NOTICE

Grounding the transmitter case using the threaded conduit protector may not provide a sufficient ground. The transient protection terminal block (option code T1) will not provide transient protection unless the transmitter case is properly grounded.

Do not run transient protection ground wire with signal wiring; the ground wire may carry excessive current if a lightning strike occurs.

#### Related information

[Grounding](#)

### Signal wire grounding


### NOTICE

Do not run signal wiring in conduit or open trays with power wiring or near heavy electrical equipment. Ground the shield of the signal wiring at any one point on the signal loop.

See [Figure 3-14](#). The negative terminal of the power supply is a recommended grounding point.



Figure 3-14: Signal wire grounding



- A. Positive
- B. Negative
- C. Connect shield back to the power supply negative terminal
- D. Insulate shield
- E. Minimize distance
- F. Trim shield and insulate

### Power supply 4-20 mA transmitters

The DC power supply should provide power with less than two percent ripple.

Total resistance load is the sum of resistance from signal leads and the load resistance of the controller, indicator, and related pieces. Note that the resistance of intrinsic safety barriers, if used, must be included.

#### Note

A minimum loop resistance of 250 ohms is required to communicate with a communication device. If a single power supply is used to power more than one transmitter, the power supply used and circuitry common to the transmitters should not have more than 20 ohms of impedance at 1200 Hz.

### 3.3.7 Conduit electrical connector wiring (option <sup>GE</sup> or <sup>GM</sup>)

For transmitters with conduit electrical connectors <sup>GE</sup> or <sup>GM</sup>, refer to the cordset manufacturer's installation instructions for wiring details.

For FM Intrinsically Safe, non-incendive hazardous locations, install in accordance with Rosemount drawing 03151-1009 to maintain outdoor rating (NEMA<sup>®</sup> 4X and IP66).

### 3.3.8 Grounding

#### Transmitter case

#### **⚠ WARNING**

Always ground the transmitter case in accordance with national and local electrical codes.


The most effective transmitter case grounding method is a direct connection to earth ground with minimal impedance ( $< 1\Omega$ ). Methods for grounding the transmitter case include:

### Internal ground connection

The internal ground connection screw is inside the terminal side of the electronics housing.

The screw is identified by a ground symbol ( $\oplus$ ), and is standard on all 3051SMV transmitters.

**Figure 3-15: Internal ground connection**




A. Ground lug

### External ground connection

The external ground connection is on the outside of the SuperModule™ housing. The connection is identified by a ground symbol ( $\oplus$ ). An external ground assembly is included with the option codes shown in [Table 3-6](#) or is available as a spare part (03151-9060-0001).

**Figure 3-16: External Ground Connection**



- A. External ground lug
- B. External ground assembly (03151-9060-0001)

**Table 3-6: External ground screw approval option codes**


| Option code | Description   |
|-------------|---|
| E1          | ATEX Flameproof   |
| I1          | ATEX Intrinsic Safety   |
| N1          | ATEX Type n   |
| ND          | ATEX Dust   |
| E4          | TIIS Flameproof   |
| K1          | ATEX Flameproof, Intrinsic Safety, Type n, Dust (combination of E1, I1, N1, and ND)                 |
| E7          | IECEx Flameproof, Dust Ignition-proof   |
| N7          | IECEx Type n  |
| K7          | IECEx Flameproof, Dust Ignition-proof, Intrinsic Safety, and Type n (combination of E7, I7, and N7) |
| KA          | ATEX and CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E1, E6, I1, and I6)    |
| KC          | FM and ATEX Explosion-proof, Intrinsically Safe, Division 2 (combination of E5, E1, I5, and I1)     |
| T1          | Transient terminal block  |
| D4          | External ground screw assembly  |

## 3.4 Rosemount 305 and 304 Manifolds


The Rosemount 305 Integral Manifold is available in two designs: Coplanar™ and traditional.

You can mount the 305 Traditional to most primary elements with mounting adapters.

305 Integral Coplanar




305 Integral Traditional




The Rosemount 304 comes in two basic styles: traditional (flange X flange and flange X pipe) and wafer. The 304 Traditional Manifold comes in 2-, 3-, and 5-valve configurations. The 304 Wafer Manifold comes in 3- and 5-valve configurations.

304 Traditional



304 Wafer



### 3.4.1 Install 305 Integral Manifold

#### Procedure

1. Inspect the PTFE sensor module O-rings.  
You may reuse undamaged O-rings. If the O-rings are damaged (if they have nicks or cuts, for example), replace with O-rings designed for Rosemount transmitters.

#### NOTICE

If replacing the O-rings, take care not to scratch or deface the O-ring grooves or the surface of the isolating diaphragm while you remove the damaged O-rings.

2. Install the integral manifold on the sensor module. Use the four 2¼-inch (57 mm) manifold bolts for alignment.
3. If you have replaced the PTFE sensor module O-rings, re-tighten the flange bolts after installation to compensate for cold flow of the O-rings.

### 3.4.2 Install 304 Conventional Manifold

#### Procedure

1. Align the conventional manifold with the transmitter flange. Use the four manifold bolts for alignment.
2. Finger tighten the bolts; then tighten the bolts incrementally in a cross pattern to the final torque value.  
When fully tightened, the bolts extend through the top of the sensor module housing.
3. Leak-check assembly to maximum pressure range of transmitter.

### 3.4.3 Manifold operation


#### ⚠ WARNING

Improper installation or operation of manifolds may result in process leaks, which may cause death or serious injury.

Always perform a zero trim on the transmitter/manifold assembly after installation to eliminate any shift due to mounting effects.

#### **Coplanar™ transmitters** **Perform a zero trim on 3 and 5-valve manifolds**


In normal operation, the two isolate (block) valves between the process ports and the transmitter will be open, and the equalize valve will be closed.



- A. High
- B. Low
- C. Drain/vent valve
- D. Isolate (open)
- E. Equalize (closed)
- F. Process


#### Procedure

1. To zero trim the transmitter, close the isolate valve on the low side (downstream) side of the transmitter.




- A. High
- B. Low
- C. Drain/vent valve
- D. Isolate (open)
- E. Equalize (closed)
- F. Process
- G. Isolate (closed)

- Open the equalize valve to equalize the pressure on both sides of the transmitter. The manifold is now in the proper configuration for performing a zero trim on the transmitter.




- A. High
- B. Low
- C. Drain/vent valve
- D. Isolate (open)
- E. Equalize (open)
- F. Process
- G. Isolate (closed)

- After zeroing the transmitter, close the equalize valve.



- A. High
- B. Low
- C. Drain/vent valve
- D. Isolate (open)
- E. Equalize (closed)
- F. Process
- G. Isolate (closed)


- Finally, to return the transmitter to service, open the low side isolate valve.



- A. High
- B. Low
- C. Drain/vent valve
- D. Isolate (open)
- E. Equalize (closed)
- F. Process

### Zero a five-valve natural gas manifold

In normal operation, the two isolate (block) valves between the process ports and the transmitter will be open, and the equalize valves will be closed. Vent valves may be open or closed.




- A. High
- B. Low
- C. Plugged
- D. Isolate (open)
- E. Process
- F. Equalize (closed)
- G. Drain vent (closed)




**Procedure**

1. To zero trim the transmitter, first close the isolate valve on the low pressure (downstream) side of the transmitter and the vent valve.




- A. High
- B. Low
- C. Plugged
- D. Isolate (open)
- E. Process
- F. Equalize (closed)
- G. Drain vent (closed)
- H. Isolate (closed)

2. Open the equalize valve on the high pressure (upstream) side of the transmitter.




- A. High
- B. Low
- C. Plugged
- D. Isolate (open)
- E. Process
- F. Equalize (open)
- G. Equalize (closed)
- H. Drain vent (closed)
- I. Isolate (closed)

3. Open the equalize valve on the low pressure (downstream) side of the transmitter. The manifold is now in the proper configuration for zeroing the transmitter.




- A. High
- B. Low
- C. Plugged
- D. Isolate (open)
- E. Process
- F. Equalize (open)
- G. Drain vent (closed)
- H. Isolate (closed)

4. After zeroing the transmitter, close the equalize valve on the low pressure (downstream) side of the transmitter.



- A. High
- B. Low
- C. Plugged
- D. Isolate (open)
- E. Process
- F. Equalize (open)
- G. Equalize (closed)
- H. Drain vent (closed)
- I. Isolate (closed)


5. Close the equalize valve on the high pressure (upstream) side.



- A. High  
B. Low  
C. Plugged  
D. Isolate (open)  
E. Process  
F. Equalize (closed)  
G. Drain vent (closed)  
H. Isolate (closed)

6. Finally, to return the transmitter to service, open the low side isolate valve and vent valve.

The vent valve can remain open or closed during operation.




- A. High  
B. Low  
C. Plugged  
D. Isolate (open)  
E. Process  
F. Equalize (closed)  
G. Drain vent (closed)

## In-line transmitters 2-valve and block and bleed style manifolds

### Isolating the transmitter


In normal operation, the isolate (block) valve between the process port and transmitter will be open and the test/vent valve will be closed. On a block and bleed style manifold, a single block valve provides transmitter isolation, and a bleed screw provides drain/vent capabilities.



- A. Transmitter
- B. Vent (closed)
- C. Isolate
- D. Process (open)


### Procedure

1. To isolate the transmitter, close the isolate valve.



- A. Transmitter
- B. Vent (closed)
- C. Isolate
- D. Process (closed)

2. To bring the transmitter to atmospheric pressure, open the vent valve or bleed screw.




- A. Transmitter
- B. Vent (open)
- C. Isolate
- D. Process (closed)

### Note


A 1/4-in (6.35 mm). male NPT pipe plug may be installed in the test/vent port; you will need to remove it with a wrench in order to vent the manifold properly. Always use caution when venting directly to atmosphere.

3. After venting to atmosphere, perform any required calibration and then close the test/vent valve or replace the bleed screw.



- A. Transmitter
- B. Vent (closed)
- C. Isolate
- D. Process (closed)

4. Open the isolate (block) valve to return the transmitter to service.



- A. Transmitter
- B. Vent (closed)
- C. Isolate
- D. Process (open)

## Adjust valve packing

Over time, the packing material inside a Rosemount manifold may require adjustment in order to continue to provide proper pressure retention. Not all manifolds have this adjustment capability. The manifold model number will indicate what type of stem seal or packing material has been used.


### Procedure

1. Remove all pressure from device.
2. Loosen manifold valve jam nut.
3. Tighten manifold valve packing adjuster nut  $\frac{1}{4}$  turn.
4. Tighten manifold valve jam nut.
5. Re-apply pressure and check for leaks.

### Postrequisites

Repeat the above steps if necessary. If the above procedure does not result in proper pressure retention, replace the complete manifold.

Figure 3-17: Valve Components



- A. Bonnet
- B. Stem
- C. Packing
- D. Ball/tip
- E. Packing adjuster
- F. Jam nut
- G. Packing follower

## 4 Operation and maintenance

### 4.1 Overview

The document provides guidelines on calibration and configuration procedures for communication device version 2.0 or later, AMS Device Manager version 9.0 or later, and Engineering Assistant version 6.3 or later, with screen references, indications of possible measurement variations for different fluid types and explanations about Fast Keys, while noting possible differences for other multivariable types and measurement types.

This section provides instructions for performing configuration and calibration procedures for communication device version 2.0 or later, AMS Device Manager version 9.0 or later, and Engineering Assistant version 6.3 or later. Screen shots for this section are taken from AMS Device Manager version 9.0; Engineering Assistant screens look similar and follow the same instructions for use and navigation. For convenience, communication device fast key sequences are labeled **fast keys** for each software function below the appropriate headings.

Based on the configuration ordered, some measurements (such as static pressure and process temperature) and/or calculation types (such as mass, volumetric, and energy flow) may not be available for all fluid types. Available measurements and/or calculation types are determined by the MultiVariable type and measurement type codes ordered. See the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#) for more information.

All screens in this section are shown for MultiVariable type M (fully compensated mass and energy flow), measurement type 1 (differential pressure, static pressure, and process temperature). Communication device fast keys are given for both MultiVariable type M and P (direct process variable output) with measurement type 1. Communication device fast keys and screens for other MultiVariable types and measurement types may vary.

### 4.2 Transmitter calibration

#### 4.2.1 Calibration overview

Complete transmitter calibration involves the following tasks:

##### Configure the output parameters

- **Basic setup** screen
- Set **process variable units**
- Set **primary variable**
- **Rerange**
- Set **transfer function** (direct process variable feature board only)
- Set **damping**

## Calibrate the sensor (differential pressure [DP], pressure [P], and/or temperature [T])

For every sensor, execute procedures for sensor trim overview and either zero trim or a combination of upper and lower sensor trims.

For each sensor, perform:


- [Sensor trim overview](#)
- [Zero trim](#) or [Upper sensor trim and lower sensor trim](#)

## Calibrate the 4–20 mA output

- 4–20 mA analog trim or
- 4–20 mA scaled output trim (see [Scaled Analog Trim](#))

[Figure 4-1](#) summarizes the data flow for the Rosemount 3051SMV. Data flows from left to right, and a parameter change affects all values to the right of the changed parameter.

**Figure 4-1: Transmitter Data Flow**



- A. Measured process inputs
- B. Differential pressure (DP)
- C. Pressure (P)
- D. Temperature (T)
- E. Analog to digital (A/D)
- F. Micro
- G. Digital to analog (D/A)
- H. Analog mA output (primary variable)
- I. Digital HART variables (primary, 2nd, 3rd, 4th)

Data flow can be summarized in four major steps:

### Procedure

1. A change in a process variable (**differential pressure [DP], pressure [P], and/or temperature [T]**) corresponds to a change in the sensor output (**Sensor Signal**).
2. The sensor signal is converted to a digital format that is understood by the microprocessor (**Analog-to-Digital Signal Conversion**).
3. Corrections and flow calculations are performed in the microprocessor to obtain a digital representation of the process output variables.
4. The **Digital Primary Variable (PV)** is converted to an analog value (**Digital-to-Analog Signal Conversion**).

### Note

Coplanar transmitter configurations measuring gage pressure and process temperature (measurement 5) will report as the pressure as differential pressure.



This will be reflected on the LCD display, nameplate, digital interfaces, and other user interfaces.

---

#### Related information

[Analog Output Trim](#)

## 4.2.2 Sensor trim overview

Trim the sensors using either **sensor trim** or **zero trim** functions.

Trim functions vary in complexity and are application-dependent. Both trim functions alter the transmitter's interpretation of the input signal.

### Zero trim

**Zero trim** is single-point offset adjustment. It is useful for compensating for mounting position effects and is most effective when performed with the transmitter installed in its final mounting position.

Since this correction maintains the slope of the characterization curve, do not use it in place of a **sensor trim** over the full sensor range.

---

#### Note

The transmitter must be within five percent or less of the maximum span of true zero (zero-based) in order to calibrate with **zero trim** function.

---

#### Note

Do not perform a zero trim on absolute pressure transmitters. Zero trim is zero based, and absolute pressure transmitters reference absolute zero. To correct mounting position effects on absolute pressure transmitters, perform a **lower sensor trim**. The **lower sensor trim** function provides an offset correction similar to the **zero trim** function, but it does not require zero-based input.

---

#### Related information

[Rosemount 305 and 304 Manifolds](#)

## Upper sensor trim and lower sensor trim

**Sensor trim** is a two-point sensor calibration where two end-point pressures are applied, and all output is linearized between them.

Always adjust the **lower sensor trim** value first to establish the correct offset. Adjustment of the **upper sensor trim** value provides a slope correction to the characterization curve based on the **lower sensor trim** value. The trim values allow the user to optimize performance over a specified measuring range at the calibration temperature.


## 4.2.3 Differential pressure sensor calibration

**Mass and energy flow fast keys** 1, 2, 5, 3

**Direct process variable output fast keys** 1, 2, 4, 3

The **Differential Pressure Calibration** tab allows you to complete a **zero trim** procedure or a full **differential pressure (DP) sensor trim**, see [Figure 4-2](#).

Figure 4-2: Calibration → Differential Pressure Calibration tab



## Calibration Type

The **Calibration Type** drop-down menu allows the user to note the type of device last used to calibrate the sensor (either **Differential**, **Gage**, or **Absolute**). This field does not affect the calibration of the device.

## Recall Factory Trim

The **Recall Factory Trim** button will restore the transmitter to the original factory characterization curve. The **Recall Factory Trim** button can be useful for recovering from an inadvertent zero trim or inaccurate pressure source.

When the **Recall Factory Trim** function is used, the transmitter's **Upper Trim** value and **Lower Trim** value are set to the values configured at the factory. If custom trim values were specified when the transmitter was ordered, the device will recall those values. If custom trim values were not specified, the device will recall the **Upper Sensor Limit** and **Lower Sensor Limit**.

## Last Differential Pressure (DP) Sensor Trim Point

View the current **Upper Trim Point** and **Lower Trim Point** under the **Last DP Sensor Trim Point** heading.

### 4.2.4


## Static Pressure Calibration

**Mass and energy flow fast keys** 1, 2, 5, 4

**Direct process variable output fast keys** 1, 2, 4, 4

**Figure 4-3: Calibration → Static Pressure Calibration Tab**

The **Static Pressure Calibration** tab allows the user to complete either a **Zero Trim** procedure or a full SP sensor trim.



## Zero Trim and Lower Sensor Trim

The type of static pressure sensor equipped in the transmitter can be determined by referring to the **Static Pressure Sensor Trim** heading. This determines whether a **Zero Trim** (gage sensor) or **Lower Sensor Trim** (absolute sensor) required to correct for mounting position effects.

To perform a **Zero Trim** on a gage static pressure sensor, select the **Zero Trim** button under the **Static Pressure Sensor Trim** heading and follow the on-screen prompts. The transmitter must be within five percent or less of the maximum span of true zero (zero-based) in order to calibrate with **Zero Trim** function.

To correct for mounting position effects on transmitters equipped with an absolute static pressure sensor, perform a **Lower Sensor Trim**. This is accomplished by selecting the **Lower Sensor Trim** button and following the on-screen prompts. The **Lower Sensor Trim** function provides an offset correction similar to the **Zero Trim** function, but it does not require a zero-based input.

## Static Pressure Full Sensor Trim

To perform a **Static Pressure Full Sensor Trim**, perform the following procedure:

### Procedure

1. Select the **Lower Sensor Trim** button and follow the on-screen prompts.
2. Select the **Upper Sensor Trim** button and follow the on-screen prompts.

### Note

It is possible to degrade the performance of the transmitter if the full sensor trim is done improperly or with inaccurate calibration equipment. Use a pressure input source that is at least three times more accurate than the transmitter and allow the pressure input to stabilize for ten seconds before entering any values.

## Last Static Pressure Sensor Trim Points

The current **Upper Trim Point** and **Lower Trim Point** can be seen under the **Last Static Pressure Sensor Trim Points** heading.


## 4.2.5 Process temperature sensor calibration

**Mass and energy flow fast keys** 1, 2, 5, 5

**Direct process variable output fast keys** 1, 2, 4, 5

The **Temperature Calibration** tab allows you to perform a sensor trim and configure the sensor matching of a process temperature sensor. See [Figure 4-4](#).

**Figure 4-4: Calibration → Temperature Calibration Tab**



## Process temperature Upper Sensor Trim and Lower Sensor Trim

The procedure involves setting up a Temperature Calibrator to simulate a Pt 100 RTD, adjusting the calibrator to represent minimum and maximum process temperatures, and following the prompts on the Process Temperature Sensor Trim for both measurements.

### Procedure

1. Set up a temperature calibrator to simulate a Pt 100 (100-ohm platinum, alpha 385 RTD). Wire the two red wires from the Rosemount 3051SMV terminal block to one connection, and the two white wires to the other connection.
2. Adjust the calibrator/RTD simulator to a test point temperature value that represents a minimum process temperature (for example, +32 °F or 0 °C). Select

the **Lower Sensor Trim** button under the **Process Temperature Sensor Trim** heading and follow the on-screen prompts.

- Adjust the calibrator/RTD simulator to a test point temperature value that represents the maximum process temperature (for example, 140 °F or 60 °C). Select the **Upper Sensor Trim** button under the **Process Temperature Sensor Trim** heading and follow the on-screen prompts.

#### Related information

[Install optional process temperature input \(Pt 100 RTD sensor\)](#)

### Transmitter RTD sensor matching using Callendar-Van Dusen constants

The Rosemount 3051SMV accepts Callendar-Van Dusen constants from a calibrated RTD schedule and generates a special custom curve to match that specific sensor Resistance vs. Temperature performance. Matching the specific sensor curve with the transmitter configuration enhances the temperature measurement accuracy.


Under the **Sensor Matching** heading, the Callendar-Van Dusen constants  $R_0$ , A, B, and C can be viewed. If the Callendar-Van Dusen constants are known for the user's specific Pt 100 RTD sensor, the constants  $R_0$ , A, B, and C may be edited by selecting the **Callendar-Van Dusen Setup** button and following the on-screen prompts. The user may also view the  $\alpha$ ,  $\beta$ , and  $\delta$  Coefficients by selecting the **View Alpha Beta Delta** button. To reset the transmitter to the IEC 751 Defaults, select the **Reset to IEC 751 Defaults** button.

## 4.2.6 Analog calibration

**Mass and energy flow fast keys** 1, 2, 5, 2

**Direct process variable output fast keys** 1, 2, 4, 5

Figure 4-5: Calibration → Analog Calibration tab



## Analog Output Trim

The **Analog Output Trim** commands allow you to adjust the transmitter's current output at the 4 and 20 mA points to match the plant standards.

This command adjusts the digital to analog signal conversion, see [Figure 4-5](#).

To perform an analog trim, select the **Analog Trim** button and follow the on-screen prompts.

## Scaled Analog Trim

The **Scaled Analog Trim** command matches the 4 and 20 mA points to a user selectable reference scale other than 4 and 20 mA (for example, 1 to 5 volts if measuring across a 250 ohm load, or 0 to 100 percent if measuring from a Distributed Control System [DCS]). To perform a scaled analog trim, connect an accurate reference meter, select the **Scaled Analog Trim** button, and follow the on-screen prompts.

---

### Note

Use a precision resistor for optimum accuracy. When adding a resistor to the loop, ensure that the power supply is sufficient to power the transmitter to a 23 mA (maximum high alarm) output with the additional loop resistance.

---

## Analog output loop test

**Mass and energy flow fast keys** 1, 2, 2

**Direct process variable output fast keys** 1, 2, 2

Under the **Analog Output Verify** heading, select the **Loop Test** button to perform a loop test. The **Loop Test** command verifies the output of the transmitter, the integrity of the loop, and the operations of any recorders or similar devices installed in the loop.

## Analog output diagnostic alerts


Two diagnostic alerts are shown under the **Diagnostics** heading.

The first is **mA Output Fixed**. This alerts the user that the 4–20 mA analog output signal is fixed at a constant value and is not representative of the **HART Primary Variable**. This diagnostic alert may also be triggered if **Loop Current Mode** is disabled, the device is in alarm, or if **Test Calculation** is running.

The second diagnostic is **mA Output Saturated**. This alerts the user that the measured **Primary Variable** has exceeded the range points defined for the 4–20 mA analog output signal. The analog output is fixed at the user-defined high or low saturation point and is not representative of the current **HART Primary Variable**.

## 4.3 Transmitter functional tests

Figure 4-6: *Transmitter Functional Tests* screen



### 4.3.1 *Flow/Energy Calculation Verification* (test calculation)

Mass and energy flow fast keys 1, 2, 3

(Fully compensated mass and energy flow feature board only):

The **Flow and Energy Calculation Verification** Test allows the user to verify the flow configuration of the Rosemount 3051SMV by entering expected values for the differential pressure, static pressure, and process temperature variables. Under the **Flow/Energy Calculation Verification** heading, perform the following steps:

#### Procedure

1. Select the **Enable Test Calculation** button.
2. Select **Simulate DP** option. Select **Next**.
3. Select **DP Units** from the drop-down menu. Select **Next**.
4. Enter the **DP Value** corresponding to the desired flow rate simulation. Select **Next**.
5. Repeat steps **Step 1–Step 3** for static pressure (**Simulate AP/GP**) and process temperature (**Simulate PT**), if applicable.
6. Select **View Results**. Select **Next**. The simulated flow rate and corresponding flow properties will be shown. Select **Next**.
7. Select **Exit**. Select **Next**. Leaving the **Enable Test Calculation** window automatically returns all process variables fixed by the test calculation method to live process variable measurements.

## 4.3.2 Configuring fixed process variables

Mass and energy flow fast keys 1, 2, 4

Direct process variable output fast keys 1, 2, 3

Under the **Fixed Process Variables** heading, you can temporarily set the differential pressure, static pressure or process temperature to a user defined fixed value for testing purposes. Once the user leaves the **Configure Fixed Variable** method, the fixed process variable will be automatically returned to a live process variable measurement.

## 4.3.3 Analog output loop test

Mass and energy flow fast keys 1, 2, 2

Direct process variable output fast keys 1, 2, 2

Under the **Analog Output Verify** heading, select the **Loop Test** button to perform a loop test. The **Loop Test** command verifies the output of the transmitter, the integrity of the loop, and the operations of any recorders or similar devices installed in the loop.

## 4.4 Process variables

### 4.4.1 Process variable tabs

Mass and energy flow fast keys 1, 1


Direct process variable output fast keys 1, 1

The **Process Variables** screen shows a graphical representation of the respective variable. See [Figure 4-7](#) for an example of the **Primary Variable** tab. The chart on these **Process Variables** tabs will begin plotting when you first navigate to the screen, and will only continue plotting while the user is viewing this tab. The user may view a larger version of the chart by selecting the **Large Chart** button.

Each of the four digital output variables has a screen similar to the one shown in [Figure 4-7](#).




Figure 4-7: Process Variables → Primary Variable Tab



## 4.4.2 All Variables tab

The **All Variables** tab allows the user to view a complete overview of all variables available within the device.

Figure 4-8: Process Variables → All Variables Tab



## 4.5 Field upgrades and replacements

### 4.5.1 Disassembly considerations

#### **⚠ WARNING**

During disassembly, do not remove any instrument covers in explosive atmospheres when the circuit is live, as this may result in serious injury or death.

Be aware of the following:

- Follow all plant safety rules and procedures.
- Before removing the transmitter from service, isolate and vent the process from the transmitter.
- Disconnect optional process temperature sensor leads and cable.
- Remove all other electrical leads and conduit.
- Detach the process flange by removing the four flange bolts and two alignment screws that secure it.
- Do not scratch, puncture, or depress the isolating diaphragms.
- Clean isolating diaphragms with a soft rag and a mild cleaning solution, then rinse with clear water.
- Whenever the process flange or flange adapters are removed, visually inspect the PTFE O-rings. Emerson recommends reusing O-rings if possible. If the O-rings show any signs of damage, such as nicks or cuts, they must be replaced.

### 4.5.2 Housing assembly including feature board electronics

#### **Field device labels**

The SuperModule™ label reflects the replacement model code for reordering a complete transmitter, including both the SuperModule assembly and Plantweb™ housing. The transmitter model code stamped on the Plantweb housing nameplate can be used to reorder the Plantweb housing assembly.

#### **Upgrading feature board electronics**

The transmitter supports feature board electronics upgrades.

Different feature board electronics assemblies provide new functionality and are easily interchanged for upgrade. When replacing or upgrading the feature board electronics, use the Rosemount 300SMV housing kit, which also includes the appropriate Plantweb™ housing.

#### **Upgrading or replacing the housing assembly including feature board electronics**

##### **Remove the feature board**


The procedure outlines how to access the SuperModule connector on the feature board inside the Plantweb™ housing by removing the housing cover, LCD display, and two screws on the feature board.

The feature board is located opposite the field terminal side in the Plantweb™ housing.

### Procedure

1. Remove the housing cover opposite the field terminal side.
2. Remove the LCD display, if applicable. To do this, hold in the two clips and pull outward. This will provide better access to the two screws located on the feature board.
3. Loosen the two captive screws located on the feature board.
4. Pull out the feature board to expose and locate the SuperModule connector, see [Figure 4-10](#).
5. Press the locking tabs and pull the SuperModule connector upwards (avoid pulling wires). Housing rotation may be required to access locking tabs. See [Rotate housing](#) for more information.

**Figure 4-9: SuperModule Connector View**




- A. Feature board
- B. SuperModule connector

### Separate the SuperModule™ assembly from the housing

#### Procedure

1. To prevent damage to the SuperModule connector, remove the feature board from the SuperModule assembly and remove the connector before separating the SuperModule assembly from the housing.
2. Loosen the housing rotation set screw by one full turn with a 3/32-in. hex wrench.
3. Unscrew the housing from the SuperModule threads.

**Figure 4-10: SuperModule Connector**



- A. 3/32-in. housing rotation set screw


---

**Note**

The V-Seal (03151-9061-0001) must be installed at the bottom of the housing.

---

**Figure 4-11: V-Seal**



A. Black rubber V-seal

---

### Attach the SuperModule™ assembly to the Plantweb™ housing

#### Procedure

1. Apply a light coat of low temperature silicon grease to the SuperModule threads and O-ring.
2. Thread the housing completely onto the SuperModule assembly.

#### **⚠ WARNING**

The housing must be no more than one full turn from flush with the SuperModule assembly to comply with flameproof/explosion-proof requirements.

---

3. Tighten the housing rotation set screw using a 3/32-in. hex wrench to a recommended torque of 30 in-lb (3.4 N-m).

### Install feature board in the Plantweb™ housing

#### Procedure

1. Apply a light coat of low temperature silicon grease to the SuperModule™ connector O-ring.
2. Insert the SuperModule connector into the top of the SuperModule assembly. Ensure the locking tabs are fully engaged.
3. Gently slide the feature board into the housing, making sure the pins from the Plantweb housing properly engage the receptacles on the feature board.
4. Tighten the captive screws.
5. Attach the Plantweb housing cover and tighten so that metal contacts metal to meet flameproof/explosion-proof requirements.


## Terminal block

The instructions detail how to replace or upgrade the terminal block in the **FIELD TERMINALS** compartment of the Plantweb housing, which involves removing and reinstalling the terminal block and the housing cover.

Electrical connections are located on the terminal block in the compartment labeled **FIELD TERMINALS**. You may replace or upgrade the terminal block to add transient protection. See the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#) for part numbers.

Loosen the two captive screws (see [Figure 4-12](#)), and pull the entire terminal block out.

**Figure 4-12: Terminal Blocks**



A. Captive screws

### Procedure

1. Gently slide the terminal block into the housing, making sure the pins from the Plantweb housing properly engage the receptacles on the terminal block.
2. Tighten the captive screws on the terminal block.
3. Attach the Plantweb housing cover and tighten so that metal contacts metal to meet flameproof/explosion-proof requirements.

## Install LCD display

Emerson ships transmitters ordered with the LCD display with the display installed. Installing the display on an existing transmitter requires the LCD display kit (part number 03151-9193-0001 for aluminum housing and 03151-9193-0004 for stainless steel (SST) housing).

### Procedure


1. If the transmitter is installed in a loop, secure the loop and disconnect power.
2. Remove the transmitter cover on the feature board side (opposite the field terminals side).

### **▲ WARNING**

Do not remove the instrument covers in explosive environments when the circuit is live.

3. Engage the four-pin connector into the feature board and snap the LCD display into place.
4. Install the display cover and tighten to ensure metal to metal contact in order to meet flameproof/explosion-proof requirements.

**Figure 4-13: Optional LCD display**



- A. Feature board
- B. LCD display
- C. Display cover


## Flange and drain vent

The Rosemount 3051SMV is attached to the process connection flange by four bolts and two alignment cap screws.

### Procedure

1. Remove the two alignment cap screws.

**Figure 4-14: Alignment Cap Screws**



- A. Alignment cap screw

2. Remove the four bolts and separate the transmitter from the process connection, but leave the process connection flange in place and ready for re-installation.

### Note

If the installation uses a manifold, see [Manifold operation](#).

3. Inspect the SuperModule PTFE O-rings. If the O-rings are undamaged, they may be reused.

## NOTICE

Emerson recommends reusing O-rings if possible. If the O-rings show any signs of damage, such as nicks or cuts, they should be replaced (part number 03151-9042-0001 for glass-filled PTFE and part number 03151-9042-0002 for graphite-filled PTFE). If replacing the O-rings, be careful not to scratch or deface the O-ring grooves or the surface of the isolating diaphragm when removing the damaged O-rings.

4. Install the process flange on the SuperModule process connection. To hold the process flange in place, install the two alignment cap screws finger tight.

## NOTICE

**These screws are not pressure retaining.**

Do not overtighten; this will affect module-to-flange alignment.

5. Install the appropriate flange bolts.
  - a) If the installation requires a 1/4-18 NPT connection(s), use four 1.75-in. flange bolts. Finger tighten the bolts. Go to [5.d](#).
  - b) If the installation requires a 1/2-14 NPT connection(s), use flange adapters and four 2.88-in. process flange/adaptor bolts.
  - c) Hold the flange adapters and adapter O-rings in place while finger-tightening the bolts.
  - d) Tighten the bolts to the initial torque value using a crossed pattern. See [Table 4-1](#) for appropriate torque values.
  - e) Tighten the bolts to the final torque value using a crossed pattern. See [Table 4-1](#) for appropriate torque values. When fully tightened, the bolts should extend through the top of the module housing.
  - f) Torque alignment screws to 30 in-lb (3.4 N-m). If the installation uses a conventional manifold, then install flange adapters on the process end of the manifold using the 1.75-in. flange bolts supplied with the transmitter.

**Table 4-1: Bolt Installation Torque Values**

| Bolt material                        | Initial torque value | Final torque value |
|--------------------------------------|----------------------|--------------------|
| Carbon steel (CS)-ASTM-A449 Standard | 300 in-lb (34 N-m)   | 650 in-lb (73 N-m) |
| 316 stainless steel (SST)—Option L4  | 150 in-lb (17 N-m)   | 300 in-lb (34 N-m) |
| ASTM-A-193-B7M—Option L5             | 300 in-l (34 N-m)    | 650 in-lb (73 N-m) |
| Alloy K-500—Option L6                | 300 in-lb (34 N-m)   | 650 in-lb (73 N-m) |
| ASTM-A-453-660—Option L7             | 150 in-lb (17 N-m)   | 300 in-lb (34 N-m) |
| ASTM-A-193-B8M—Option L8             | 150 in-lb (17 N-m)   | 300 in-lb (34 N-m) |

6. If the SuperModule PTFE O-rings are replaced, re-torque the flange bolts and alignment cap screws after installation to compensate for seating of the PTFE O-ring.
7. Install the drain/vent valve.
  - a) Apply sealing tape to the threads on the seat. Starting at the base of the valve with the threaded end pointing toward the installer, apply two clockwise turns of sealing tape.
  - b) Take care to place the opening on the valve so that process fluid will drain toward the ground and away from human contact when the valve is opened.
  - c) Tighten the drain/vent valve to 250 in-lb (28.25 N-m).
  - d) Tighten the stem to 70 in-lb (8 N-m).

---

**Note**

Due to the sensitivity of the Range 1 DP Sensor, extra steps are required to optimize performance. It is necessary to temperature soak the assembly using the following procedure.

- a. After replacing O-rings on DP Range 1 transmitters and re-installing the process flange, expose the transmitter to a temperature of 185 °F (85 °C) for two hours.
  - b. Re-tighten the flange bolts in a cross pattern.
  - c. Again, expose the transmitter to a temperature of 185 °F (85 °C) for two hours before calibration.
- 

## Replace SuperModule™ assembly

To reorder an upgrade or replacement SuperModule assembly, use the Rosemount 3051SMV ordering information but replace the housing option code with '00'.

### Procedure

1. Remove the housing assembly per [Upgrading or replacing the housing assembly including feature board electronics](#) .
2. Remove currently installed SuperModule assembly from process flange per [Flange and drain vent](#).
3. Reassemble replacement or upgraded SuperModule assembly to process flange per [Flange and drain vent](#).
4. Reassemble the housing assembly per [Upgrading or replacing the housing assembly including feature board electronics](#) .



# 5 Troubleshooting

## 5.1 Overview

This section contains information for troubleshooting the transmitter. Diagnostic messages are communicated via the LCD display or a HART® host.

## 5.2 Device diagnostics

### 5.2.1 HART® host diagnostics

The transmitter issues various diagnostic alerts via a HART host, which can be viewed using specified tools, with guidance for each alert and troubleshooting suggestions provided in designated resources.

The transmitter provides numerous diagnostic alerts via a HART host. These alerts can be viewed in Engineering Assistant 6.3 or later, communication device, or AMS Device Manager.

[LCD display diagnostics](#) lists the possible diagnostic alerts that may be shown with the transmitter. The tables also give a brief description of what each alert indicates and the recommended actions.

[Transmitter troubleshooting](#) provides summarized maintenance and troubleshooting suggestions for the most common operating problems. If a malfunction is suspected despite the absence of any diagnostic messages on the communication device or host, follow the procedures described here to verify that transmitter hardware and process connections are in good working order.

### 5.2.2 LCD display diagnostics

In addition to output, the LCD display shows abbreviated operation, error, and warning messages for troubleshooting.

Messages appear according to their priority; normal operating messages appear last. To determine the cause of a message, use a HART® host to further interrogate the transmitter. A description of each LCD display diagnostic message follows.

#### Error messages

An error indicator message appears on the LCD display to warn of serious problems affecting the operation of the transmitter. The LCD display shows an error message until the error condition is corrected; **ERROR** appears at the bottom of the display.

#### Warning messages

Warning messages appear on the LCD display to alert you of user-repairable problems with the transmitter, or current transmitter operations. Warning messages appear alternately

with other transmitter information until the warning condition is corrected or the transmitter completes the operation that warrants the warning message.

## Diagnostic message troubleshooting AP GP LIMIT

**LCD display message** AP GP LIMIT

**Host diagnostic message** Static Pressure Out of Limits

### Potential cause

The static pressure is exceeding the sensor limits.

#### Recommended action

Verify process conditions are within the sensor limits.

## BOARD COMM ERROR

**LCD display message** BOARD COMM ERROR

**Host diagnostic message** Feature Board Communication Error

### Potential cause

The feature board electronics are experiencing communication problems. This problem may be temporary and could clear automatically.

#### Recommended actions

1. Cycle power to the device.
2. If the problem persists, replace the feature board electronics.

## CURR SAT

### LCD display message

**LCD display message** CURR SAT

**Host diagnostic message** Primary Variable Analog Output Saturated

### Potential cause

The primary variable has exceeded the range points defined for the 4-20 mA analog output signal. The analog output is fixed at the **high** or **low saturation point** and is not representative of the current process conditions.

#### Recommended action

Verify the process conditions and modify the **Analog Range** values if necessary.

## DP LIMIT

**LCD display message** DP LIMIT

**Host diagnostic message** Differential Pressure Out of Limits

### Potential cause

The differential pressure is exceeding the sensor limits.

### Recommended action

Verify that process conditions are within the sensor limits.

## FAIL BOARD ERROR

**LCD display message** FAIL BOARD ERROR

**Host diagnostic message** Feature Board Error

### Potential cause

The feature board electronics have detected an unrecoverable failure.

### Recommended action

Replace the feature board electronics.

## FAIL PT ERROR

**LCD display message** FAIL PT ERROR

**Host diagnostic message** Process Temperature Sensor Failure

### Potential cause

The process temperature sensor has failed or is incorrectly wired.

### Recommended actions

1. Check the sensor wiring and fix any shorts or open connections.
2. If the sensor wiring is correct, check the process temperature sensor and replace if necessary.
3. If the problem persists, replace the feature electronics board.

## FAIL SENSOR ERROR

**LCD display message** FAIL SENSOR ERROR

**Host diagnostic message** Sensor Module Failure

### Potential cause

The SuperModule™ assembly is providing measurements that may no longer be valid.

### Recommended actions

1. Verify the sensor module temperature is within the operating limits of the transmitter.
2. Replace SuperModule assembly if necessary.

## FLOW CONFIG

**LCD display message** FLOW CONFIG

**Host diagnostic message** Updating Flow Configuration - Flow Values Constant

#### Potential cause

A flow configuration is currently being downloaded to the transmitter. During the download, the flow output will be fixed at the last calculated value. Once the download is complete, the transmitter will resume live calculations.

#### Recommended action

No action is required. Wait until the flow configuration download is complete before performing other configuration tasks.

### FLOW INCOMP ERROR

**LCD display message** FLOW INCOMP ERROR

**Host diagnostic message** Energy Invalid for Flow Configuration

#### Potential cause

The **Energy Flow** variable is not compatible with the current flow configuration, but is mapped to the totalizer, a process variable, or a burst variable.

#### Recommended actions

1. Verify configuration for the fluid type supports **Energy Flow** calculation.
2. Do not specify Energy Flow for the totalizer, process variables, or burst variables unless the transmitter has a compatible flow configuration.

### FLOW INCOMP ERROR

**LCD display message** FLOW INCOMP ERROR

**Host diagnostic message** Static Pressure Sensor Missing

#### Potential cause

A static pressure sensor is needed for the current flow configuration.

#### Recommended action

Download a flow configuration that is compatible with the sensors equipped in the device or replace the module with a model that includes a static pressure sensor.

### FLOW INCOMP ERROR

**LCD display message** FLOW INCOMP ERROR

**Host diagnostic message** Flow Configuration Download Error

#### Potential cause

The flow configuration did not successfully download to the transmitter.

#### Recommended action

Re-download the flow configuration using the Engineering Assistant software.

## FLOW LIMIT

**LCD display message** FLOW LIMIT

**Host diagnostic message** Flow Output Out of Limits

### Potential cause

The flow output value is exceeding the flow rate operating limits.

#### Recommended action

Verify the process conditions and modify the flow configuration parameters and operating ranges as needed.

## FLOW LIMIT

**LCD display message** FLOW LIMIT

**Host diagnostic message** Energy Flow Out of Limits

### Potential cause

The **Energy Flow** value is exceeding the flow rate operating limits.

#### Recommended action

Verify the process conditions and modify the flow configuration parameters and operating ranges as needed.

## LCD UPDATE ERROR

**LCD display message** LCD UPDATE ERROR

**Host diagnostic message** LCD Update Error

### Potential cause

The LCD display is not receiving updates from the electronics feature board.

#### Recommended actions

1. Examine the LCD display connector and reset the LCD display.
2. If the problem persists, first replace the LCD display and then replace the feature board electronics if necessary.

## LCD is blank

**LCD display message** (LCD is blank)

**Host diagnostic message** LCD Update Error

### Potential cause

The LCD display is no longer powered.

#### Recommended actions

1. Examine the LCD display connector and reset the LCD display.

2. If the problem persists, first replace the LCD display and then replace the feature board electronics if necessary.

## PT LIMIT

LCD display  
message

**PT LIMIT**

Host diagnostic  
message

**Process Temperature Out of Limits**

### Potential cause

The process temperature sensor is exceeding the user-defined sensor limits.

#### Recommended actions

1. Verify the process conditions and adjust limits if necessary.
2. Check the process temperature sensor and replace if necessary.

## RVRSE FLOW

LCD display  
message

**RVRSE FLOW**

Host diagnostic  
message

**Reverse Flow Detected**

### Potential cause

The transmitter is measuring a negative differential pressure.

#### Recommended action

Verify the process conditions and the transmitter installation.

## SNSR COMM ERROR

LCD display  
message

**SNSR COMM ERROR**

Host diagnostic  
message

**Module Communication Failure**

### Potential cause

Communication between the sensor module and the feature board electronics have been lost.

#### Recommended actions

1. Verify the connection between the sensor module and the feature board electronics.
2. Replace the SuperModule™ assembly and/or feature board electronics if necessary.

## SNSR INCOMP ERROR

LCD display  
message

**SNSR INCOMP ERROR**

Host diagnostic  
message

**Sensor Module Incompatibility**

### Potential cause

The SuperModule™ assembly is not compatible with the feature board electronics. The SuperModule assembly is not equipped with a differential pressure sensor or it is an older revision of the sensor module.

### Recommended action

Replace the SuperModule assembly with one that is compatible with the transmitter Plantweb™ housing.

## SNSR MISSING ERROR

LCD display message      **SNSR MISSING ERROR**

Host diagnostic message      **Sensor Missing**

### Potential cause

The sensor mapped to the primary variable is not present.

### Recommended action

Remap the primary variable to a sensor that is present.

## SNSRT LIMIT

LCD display message      **SNSRT LIMIT**

Host diagnostic message      **Sensor Temperature Out of Limits**

### Potential cause

The sensor module temperature is exceeding the sensor limits.

### Recommended action

Verify ambient conditions are within the sensor limits.

## XMTR INFO

LCD display message      **XMTR INFO**

Host diagnostic message      **Non-Volatile Memory Warning**

### Potential cause

Transmitter information data is incomplete. Transmitter operation will not be affected.

### Recommended action

Replace the electronics feature board at the next maintenance shutdown.

## XMTR INFO ERROR

LCD display message      **XMTR INFO ERROR**

Host diagnostic message      **Non-Volatile Memory Error**

#### Potential cause

Non-volatile data of the device is corrupt.

#### Recommended action

Replace the electronics feature board.

### Maintenance Required

**LCD display message** LCD display message will vary.

**Host diagnostic message** **Maintenance Required**

#### Potential cause

The transmitter may not be operating properly and requires attention.

#### Recommended action

Check other warning messages.

### mA Output Fixed

**LCD display message** LCD display message will vary.

**Host diagnostic message** **mA Output Fixed**

#### Potential cause

The 4-20 mA analog output signal is fixed at a constant value and is not representative of the HART® primary variable.

#### Recommended action

Disable **Loop Current** mode.

### Primary variable out of limits

**LCD display message** LCD display message will vary.

**Host diagnostic message** **Primary variable out of limits**

#### Potential cause

The primary variable is outside the range of the transmitter.

#### Recommended action

View other diagnostic messages to determine which variable is out of limits.

### Non-primary variable out of limits

**LCD display message** LCD display message will vary.

**Host diagnostic message** **Non-primary variable out of limits**

#### Potential cause

A variable other than the primary variable is outside the range of the transmitter.



#### Recommended action

View other diagnostic messages to determine which variable is out of limits.

### Configuration changed

**LCD display message** LCD display is reading normally.

**Host diagnostic message** **Configuration changed**

#### Potential cause

A modification has been made to the device configuration using a host other than AMS Device Manager.

#### Recommended action

No action is required; the message will clear after a change is made using AMS.

### Cold start

**LCD display message** LCD display is reading normally.

**Host diagnostic message** **Cold start**

#### Potential cause

Transmitter was restarted.

#### Recommended action

No action is required; message will clear automatically.

## 5.2.3 Transmitter troubleshooting

### Transmitter milliamp reading is zero

#### Recommended actions

1. Check power wires for reversed polarity.
2. Check that power wires are connected to signal terminals.
3. Verify terminal voltage is 12 to 42.4 Vdc.
4. Check for open diode across test terminal.

### Transmitter not communicating with communication device, AMS Device Manager, or Engineering Assistant

#### Recommended actions

1. Verify the output is between 4 and 20 mA or saturation levels.
2. Verify clean DC power to transmitter (maximum AC noise: 0.2 volts peak to peak).
3. Check that the loop resistance is 250 - 1321  $\Omega$ .  
Loop resistance = (power supply voltage - transmitter voltage)/loop current
4. Check if the transmitter is at an alternate HART<sup>®</sup> address.

## Transmitter milliamp output is low or high

### Recommended actions

1. Verify applied process variables.
2. Verify 4 and 20 mA range points and flow configuration.
3. Verify output is not in alarm or saturation condition.
4. Perform an analog output trim or sensor trim.

## Transmitter will not respond to changes in measured process variables

### Recommended actions

1. Check to ensure that the equalization valve is closed.
2. Check test equipment.
3. Check impulse piping or manifold for blockage.
4. Verify primary variable measurement is between the 4 and 20 mA set points.
5. Verify output is not in **Alarm** or **Saturation** condition.
6. Verify transmitter is not in **Loop Test**, **Multidrop**, **Test Calculation**, or **Fixed Variable** mode.

## Digital variable output is low or high

### Recommended actions

1. Check test equipment (verify accuracy).
2. Check impulse piping for blockage or low fill in wet leg.
3. Verify transmitter sensor trim.
4. Verify measured variables are within transmitter limits.

## Digital variable output is erratic

### Recommended actions

1. Check application for faulty equipment in process line.
2. Verify transmitter is not reacting directly to equipment turning on/off.
3. Verify damping is set properly for application.

## Milliamps reading is erratic

### Recommended actions

1. Verify power source to transmitter has adequate voltage and current.
2. Check for external electrical interference.
3. Verify transmitter is properly grounded.
4. Verify shield for twisted pair is only grounded at one end.

## Transmitter output is normal, but LCD display is off and diagnostics indicate an LCD display problem

### Recommended actions

1. Verify LCD display is installed correctly.

2. Replace LCD display.

## Transmitter indicating a flow value and/or differential pressure (DP) value during no flow condition


### Recommended actions

1. Zero DP sensor.
2. Verify DP **Low Flow Cutoff** setting.

## 5.3 Measurement quality and limit status

The transmitter is compliant with the HART® Revision 6 Standard. One of the most noticeable enhancements available with the HART 6 standard is that each variable has a measurement quality and limit status. You can view these statuses in AMS Device Manager, on a communication device, or with any HART 6 compatible host system. In AMS Device Manager, to view variable statuses, go to **Configure/Setup** → **Variables**.

Figure 5-1: Quality and Limit Status



### A. Measurement quality and limit status

Each variable status reading consists of two parts separated by a hyphen: Measurement Quality and Limit Status.

### 5.3.1 Possible measurement quality readings

**Good** – Displayed during normal device operation.

**Poor Accuracy** – Indicates the accuracy of the variable measurement has been compromised. Example: The module temperature sensor failed and is no longer compensating the differential pressure and status pressure measurements.

**Bad** – Indicates the variable has failed. Example: A differential pressure, static pressure, or process temperature sensor failure.

## 5.3.2 Possible limit status readings

**Not Limited** – Displayed during normal device operation.

**High Limited** – Indicates the current variable reading has gone above the transmitter's maximum possible reading and is no longer representative of the actual variable measurement.

**Low Limited** – Indicates the current variable reading has gone below the transmitter's minimum possible reading and is no longer representative of the actual variable measurement.

**Constant** – Indicates the variable reading is set to a fixed value. Example: The totalizer has been stopped.

## 5.4 Engineering Assistant communication

No communication between the Engineering Assistant software and the transmitter.

### Potential cause

Loop wiring (HART®)

#### Recommended actions

1. Make sure the HART protocol communication has a loop resistance value between 250 and 13211 ohms.
2. Check for adequate voltage to the transmitter.
3. Check for intermittent shorts, open circuits, and multiple grounds.
4. Check for capacitance across the load resistor.  
Capacitance should be less than 0.1 microfarad.

### Potential cause

Engineering Assistant

#### Recommended actions

1. Verify correct **COM** port is selected.
2. Verify laptop computer is not in low energy mode (certain laptops disable all **COM** ports in low energy mode).
3. Check if HART modem is properly connected.
4. Check if HART driver is loaded and installed. If using a HART USB port modem, install drivers from CD-ROM provided with USB modem.
5. Check if another HART configuration program, such as AMS Device Manager, is currently open.  
Only one HART configuration program may be opened at a time.
6. Verify the **COM** port buffer setting is set to the lowest setting (1) in the **Advanced COM Port Settings** and reboot the computer.
7. Set the **Device Address** to search **All**.

## 5.5 Measurement troubleshooting

The transmitter provides a means to display the current process variables and flow calculations. If the process variable reading is unexpected, this section provides the symptoms and possible corrective actions.

The following performance limitations may inhibit efficient or safe operation. Critical applications should have appropriate diagnostic and backup systems in place.

Pressure transmitters contain an internal fill fluid. It is used to transmit the process pressure through the isolating diaphragms to the pressure sensor module. In rare cases, oil loss paths in oil-filled pressure transmitters can be created. Possible causes include: physical damage to the isolator diaphragms, process fluid freezing, isolator corrosion due to an incompatible process fluid, etc. A transmitter with oil fill fluid loss may continue to perform normally for a period of time. Sustained oil loss will eventually cause one or more of the operating parameters to exceed published specifications as the operating point output continues to drift. Symptoms of advanced oil loss and other unrelated problems include:

- Sustained drift rate in true zero and span or operating point output or both
- Sluggish response to increasing or decreasing pressure or both
- Limited output rate or very nonlinear output or both
- Change in output process noise
- Noticeable drift in operating point output
- Abrupt increase in drift rate of true zero or span or both
- Unstable output
- Output saturated high or low

### 5.5.1 High primary variable (PV) reading

#### Potential cause

Primary element

#### Recommended actions

1. Check for restrictions at the primary element.
2. Check the installation and condition of the primary element.
3. Note any changes in process fluid properties that may affect output.

#### Potential cause

Impulse piping

#### Recommended actions

1. Check to ensure the pressure connection is correct.
2. Check for leaks or blockage.
3. Check to ensure that blocking valves are fully open.
4. Check for entrapped gas in liquid lines or for liquid in gas lines.
5. Check to ensure the density of fluid in impulse lines is unchanged.
6. Check for sediment in the transmitter process flange.
7. Make sure the process fluid has not frozen within the process flange.

#### Potential cause

Power supply

##### Recommended action

Check the output voltage of the power supply at the transmitter.  
It should be 12 to 42.4 Vdc for HART® with no load at the transmitter terminals.

#### NOTICE

Damage to the transmitter may result.

Do not use higher than the specified voltage to check the loop.

#### Potential cause

Feature board electronics

##### Recommended actions

1. Connect a personal computer and use AMS Device Manager, Engineering Assistant software, or a communication device to check the sensor limits to ensure calibration adjustments are within the sensor range and that the calibration is correct for the pressure being applied.
2. Confirm the electronics housing is properly sealed against moisture.
3. If the feature board electronics are not functioning properly, substitute new feature board electronics.

#### Potential cause

Flow configuration (fully compensated mass and energy flow feature board only)

##### Recommended action

Verify flow configuration is correct for current application.

#### Potential cause

Process temperature RTD input

##### Recommended actions

1. Verify all wire terminations.
2. Verify sensor is a Pt 100 RTD.
3. Replace Pt 100 sensor.

#### Potential cause

Sensor module

##### Recommended action

The sensor module is not field repairable. If it is defective, replace it. Check for obvious defects, such as a punctured isolating diaphragm or fill fluid loss, and contact [Emerson.com](http://Emerson.com).

## 5.5.2 Erratic primary variable (PV) reading

#### Potential cause

Primary element

**Recommended action**

Check the installation and condition of the primary element.

**Potential cause**

Loop wiring

**Recommended actions**

1. Check for adequate voltage to the transmitter.  
It should be 12 to 42.4 Vdc for HART® with no load at the transmitter terminals.
2. Check for intermittent shorts, open circuits, and multiple grounds.

**Potential cause**

Process pulsation

**Recommended action**

Adjust the damping.

**Potential cause**

Feature board electronics

**Recommended actions**

1. Connect a personal computer and use AMS Device Manager, Engineering Assistant software, or a communication device to check the sensor limits to ensure calibration adjustments are within the sensor range and that calibration is correct for the pressure being applied.
2. Confirm the electronics housing is properly sealed against moisture.
3. If the feature board electronics are not functioning properly, substitute new feature board electronics.

**Potential cause**

Impulse piping

**Recommended actions**

1. Check for entrapped gas in liquid lines or liquid in gas lines.
2. Make sure the process fluid is not frozen within the process flange.
3. Ensure that block valves are fully open and equalize valves are fully and tightly closed.

**Potential cause**

Sensor module

**Recommended action**

The sensor module is not field repairable. If you find it defective, replace it. Check for obvious defects, such as a punctured isolating diaphragm or fill fluid loss, and contact your nearest Emerson Service Center.

### 5.5.3 Low primary variable (PV) reading or no PV reading

**Potential cause**

Primary element

#### Recommended action

Check the installation and condition of the primary element. Note any changes in process fluid properties that may affect output.

#### Potential cause

Loop wiring

#### Recommended actions

1. Check for adequate voltage to the transmitter.  
It should be 12 to 42.4 Vdc for HART® with no load at the transmitter terminals.
2. Check the milliamp rating of the power supply against the total current being drawn for all transmitters being powered.
3. Check for shorts and multiple grounds.
4. Check for proper polarity at the signal terminal.
5. Check loop impedance.
6. Check the wire insulation to detect possible shorts to ground.

#### Potential cause

Impulse piping

#### Recommended actions

1. Check to ensure the pressure connection is correct.
2. Check for leaks or blockage.
3. Check to ensure blocking valves are fully open and that bypass valves are tightly closed.
4. Check for entrapped gas in liquid lines or for liquid in gas lines.
5. Check for sediment in the transmitter process flange.
6. Make sure process fluid has not frozen within the process flange.

#### Potential cause

Feature board electronics

#### Recommended actions

1. Check the sensor limits to ensure calibration adjustments are within the sensor range and that calibration is correct for the pressure being applied.
2. Confirm the electronics housing is properly sealed against moisture.
3. If the feature board electronics are still not functioning properly, substitute new feature board electronics.

#### Flow configuration

(1)

#### Recommended action

Verify flow configuration is correct for current application.

#### Potential cause

Process temperature RTD input

---

(1) Fully compensated mass and energy flow feature board only



#### Recommended actions

1. Verify all wire terminations.
2. Verify sensor is a Pt 100 RTD.
3. Replace Pt 100 sensor.

#### Sensor module

##### Recommended action

The sensor module is not field repairable. If you find it defective, replace it. Check for obvious defects, such as a punctured isolating diaphragm or fill fluid loss, and contact [Emerson.com](https://www.emerson.com).

## 5.5.4 Sluggish output response/drift

#### Potential cause

Primary element

##### Recommended action

Check for restrictions at the primary element.

#### Potential cause

Impulse piping

##### Recommended actions

1. Check for leaks or blockage.
2. Ensure blocking valves are fully open.
3. Check for sediment in the transmitter process flange.
4. Check for entrapped gas in liquid lines and for liquid in gas lines.
5. Ensure the density of fluid in impulse lines is unchanged.
6. Make sure process fluid has not frozen within the process flange.

#### Potential cause

Sensor module

##### Recommended actions

1. The sensor module is not field repairable. If you find it defective, replace it. Check for obvious defects, such as punctured isolating diaphragms or fill fluid loss and contact [Emerson.com](https://www.emerson.com).
2. Confirm the electronics housing is properly sealed against moisture.



## 6 Safety Instrumented Systems (SIS) requirements

### 6.1 Safety Instrumented Systems (SIS) certification

The transmitter's safety critical output is provided through a two-wire, 4-20 mA signal representing pressure.

The safety certified pressure transmitter is certified to: Low Demand; Type B.

SIL 2 for random integrity at HFT=0

SIL 3 for random integrity at HFT=1

SIL 3 for systematic integrity

The transmitter must be installed per manufacturer's instructions and specifications, and the materials must be compatible with process conditions.

#### NOTICE

The HART® Protocol is only used for setup, calibration, and diagnostic purposes and is not for safety critical operation.

### 6.2 Safety certified identification

All transmitters must be identified as safety certified before installing into Safety Instrumented Systems (SIS).

To identify a safety certified transmitter:

#### Procedure

1. Verify the model string contains Rosemount 3051SMV and QT.
  - If the transmitter was ordered as part of a flow meter, verify the model string reads Rosemount 3051SFx(1-7) and QT.
2. Verify software revision is 3.

### 6.3 Installation in Safety Instrumented Systems (SIS) applications

Ensure qualified personnel perform installations.

No special installation is required in addition to the standard installation practices outlined in this document.

#### ⚠ WARNING

Always ensure a proper seal by installing the electronics housing cover(s) so that metal contacts metal.

Environmental and operational limits are available in the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#).

The loop should be designed so the terminal voltage does not drop below 12.0 Vdc when the transmitter output is set to 23 mA. For more information, see the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#).

Position the **Security** switch to the (🔒) position to prevent accidental or deliberate change of configuration data during normal operation.

## 6.4 Configuring in Safety Instrumented Systems (SIS) applications

Use any HART® capable configuration tool to communicate with and verify configuration of the transmitter.

### ⚠ WARNING

Transmitter output is not safety-rated during the following: configuration changes, multidrop, and loop test. Use alternative means to ensure process safety during transmitter configuration and maintenance activities.


### 6.4.1 Damping

User-selected **damping** will affect the transmitters ability to respond to changes in the applied process. The **damping** value and response time must not exceed the loop requirements.

### 6.4.2 Alarm and saturation levels


Configure distributed control system (DCS) or safety logic solver to match transmitter configuration. [Figure 6-1](#), [Figure 6-2](#), and [Figure 6-3](#) identify the three alarm levels available and their operation values.

**Figure 6-1: Rosemount alarm levels**




- A. Transmitter failure; hardware or software alarm in **LO** position
- B. Low saturation
- C. Normal operation
- D. High saturation
- E. Transmitter failure; hardware or software alarm in **HI** position

Figure 6-2: Namur alarm level



- A. Transmitter failure; hardware or software alarm in **LO** position
- B. Low saturation
- C. Normal operation
- D. High saturation
- E. Transmitter failure; hardware or software alarm in **HI** position

Figure 6-3: Custom alarm level



- A. Transmitter failure; hardware or software alarm in **LO** position
- B. Low saturation
- C. Normal operation
- D. High saturation
- E. Transmitter failure; hardware or software alarm in **HI** position

## 6.5 Safety Instrumented Systems (SIS) operation and maintenance

### 6.5.1 Proof tests

Emerson recommends the following proof tests. Ensure that only qualified personnel perform proof tests.

Use fast keys to perform a **loop test**, **analog output trim**, or **sensor trim**. Place the **security** switch in the (🔒) position during proof test execution and reposition it in the (🔓) position after execution.

#### Related information

[Communication device Fast Keys](#)

## 6.5.2 Perform partial proof test

The partial suggested proof test involves a power cycle, checks on transmitter output, and retrieving diagnostics. Conduct high and low alarm current output tests, inspect for visible damages or leaks, and remove the bypass in order to identify potential failures in the device.

This test will detect 48 percent of possible DU failures in the device.

See the [Failure Modes, Effects and Diagnostic Analysis Report](#) and the certificates and approvals documentation.

### Prerequisites

Required tools: communication device and mA meter

### Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Use HART® communications to retrieve any diagnostics and take appropriate action.
3. Send a HART command to the transmitter to go to the high alarm current output and verify that the analog current reaches that value.

---

#### Note

This tests for compliance voltage problems such as a low loop power supply voltage or increased wiring distance. This also tests for other possible failures.

---

4. Send a HART command to the transmitter to go to the low alarm current output and verify that the analog current reaches that value.

---

#### Note

This tests for possible quiescent current related failures.

---

5. Inspect the device for any leaks, visible damage, or contamination.
6. Remove the bypass and otherwise restore the normal operation.
7. Place the **Security** switch in the (🔒) position.

## 6.5.3 Perform comprehensive proof test

The comprehensive proof test consists of performing the same steps as the partial proof test, but with a two point calibration of the pressure sensor in place of the reasonability check.

This test will detect approximately 90 percent of possible DU failures in the device.

### Prerequisites

Required tools: communication device and pressure calibration equipment

### Procedure

1. Bypass the safety function and take appropriate action to avoid a false trip.
2. Use HART® communications to retrieve any diagnostics and take appropriate action.
3. Send a HART command to the transmitter to go to the high alarm current output and verify that the analog current reaches that value.

---

#### Note

This tests for compliance voltage problems such as a low loop power supply voltage or increased wiring distance. This also tests for other possible failures.

---

4. Send a HART command to the transmitter to go to the low alarm current output and verify that the analog current reaches that value.  
This tests for possible quiescent current related failures.
5. Perform a two-point verification of the transmitter pressure over the full working range (and process temperature where applicable).

---

**Note**

If the two-point process temperature verification is performed with electrical instrumentation, this proof test will not detect any failures of the sensor.

---

6. Remove the bypass and otherwise restore the normal operation.
7. Place the **Security** switch in the (🔒) position.

---

**Note**

- The user determines the proof test requirements for impulse piping.
  - Automatic diagnostics are defined for the corrected % DU: The tests performed internally by the device during runtime without requiring enabling or programming by the user.
- 

**Related information**

[Alarm level verification](#)

## 6.6 Inspection

### 6.6.1 Visual inspection

This is not required.

### 6.6.2 Special tools

This is not required.

### 6.6.3 Product repair

The transmitter is repairable with limited replacement options.

Report all failures detected by the transmitter diagnostics or by the proof test. Submit feedback electronically at [Emerson.com/Rosemount/Report-A-Failure](https://emerson.com/Rosemount/Report-A-Failure)

**⚠ WARNING**

Ensure that only qualified personnel repair the product and replace parts.

---

### 6.6.4 Transmitter SIS reference

The Rosemount 3051SMV must be operated in accordance to the functional and performance specifications provided in the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#).

## 6.6.5 Failure rate data

The FMEDA report includes failure rates and the assumptions for how these failure rates were derived.

The report is available under **Certificates & Approvals** at the [Rosemount 3051S MultiVariable Transmitter Product Detail Page](#).

## 6.6.6 Failure values

**Safety Deviation (defines what is dangerous in a failure modes, effects, and diagnostic analysis)**

±2.0% of analog output span

**Transmitter response time**

Provided in the [Rosemount 3051S MultiVariable Extension Supplement Product Data Sheet](#)

**Self-diagnostics test interval**

At least once every 60 minutes

## 6.6.7 Product life

Product life is 50 years. This is based on worst case component wear-out mechanisms. It is not based on wear-out of process wetted materials.



## 7 Reference data

### 7.1 Product certifications

To view current Product Certifications:

#### Procedure

1. Go to the [Rosemount 3051S MultiVariable Transmitter product detail page](#).
2. Scroll as needed to the green menu bar and click **Documents & Drawings**.
3. Click **Manuals & Guides**.
4. Select the appropriate Quick Start Guide.

### 7.2 Ordering Information, Specifications, and Dimensional Drawings

To view current Rosemount™ 3051SMV Ordering Information, Specifications, and Dimensional Drawings:

#### Procedure

1. Go to the [Rosemount 3051S MultiVariable Transmitter product detail page](#).
2. Scroll as needed to the green menu bar and click **Documents & Drawings**.
3. Click **Data Sheets & Bulletins**.
4. Select the appropriate Product Data Sheet.

For more information: [Emerson.com/global](https://emerson.com/global)

©2024 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.

**ROSEMOUNT™**

