Quick Start Guide 00825-0400-7062, Rev AA June 2022

Rosemount[™] 1208 Level and Flow Transmitter

Standard mounting bracket





ROSEMOUNT

1 About this guide

This guide provides instructions for mounting the standard bracket.

1.1 Safety messages


A WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

Ensure only qualified personnel perform the installation.

1.2 Bracket hole pattern

Figure 1-1: Hole Pattern for Wall Mounting




Dimensions are in inches (millimeters).

2 Mount the standard bracket


Procedure

1. Mount the bracket on the pipe/ceiling/wall.


On pipe:




or




On ceiling/wall:



2. Ensure the adjustable holder is directed toward the ground.



3. Install and hand tighten the transmitter.



Quick Start Guide 00825-0400-7062, Rev. AA June 2022

For more information: Emerson.com

©2022 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.



ROSEMOUNT