

M11D-S Hydraulic Control System

For "HD", "T", and "G" series Double Acting
Pneumatic and Hydraulic Actuators



Table of Contents

Section 1: Introduction

1.1	System Description	1
1.2	Definitions	1
1.3	Safety Statement	1
1.4	Maintenance	2

Section 2: General Information

Section 3: Actuator Power Operation

Section 4: Actuator M11D-S Manual Operation

Section 5: System Refilling

Section 6: Document Revision

Appendix A: List of Drawings

Section 1: Introduction

1.1 System Description

M11D-S Hydraulic Control System is a compact, modular system designed for use with Bettis Double Acting Actuators. The system incorporates a piston type hand pump and a make-up oil reservoir necessitated by the differential volume of the hydraulic cylinder (the differential volume is due to the inboard piston rod displacement).

1.2 Definitions

⚠ WARNING

If not observed, user incurs a high risk of severe damage to actuator and/or fatal injury to personnel.

⚠ CAUTION

If not observed, user may incur damage to actuator and/or injury to personnel.

NOTE:

Advisory and information comments provided to assist maintenance personnel to carry out maintenance procedures.

1.3 Safety Statement

Products supplied by Bettis, in its "as shipped" condition, are intrinsically safe if the instructions contained within this Service Instruction are strictly adhered to and executed by a well trained, equipped, prepared and competent technician.

⚠ WARNING: FOLLOW WARNING AND CAUTION SIGNS

For the protection of personnel working on Bettis actuators, this procedure should be reviewed and implemented for safe disassembly and reassembly. Close attention should be noted to the WARNINGS, CAUTIONS and NOTES contained in this procedure.

⚠ WARNING: FOLLOW COMPANY SAFETY PROCEDURES

This procedure should not supersede or replace any customer's plant safety or work procedures. If a conflict arises between this procedure and the customer's procedures the differences should be resolved in writing between an authorized customers representative and an authorized Bettis representative.

1.4 Maintenance

- 1.4.1 Bettis does not recommend periodic field maintenance for the M11D-S module and pump.
- 1.4.2 The only time the M11D-S module or pump should be disassembled is when either the pump or the M11D-S module fails to perform its hydraulic control function. If maintenance is required.
- 1.4.3 When possible the M11D-S package should be returned to the factory for maintenance.

NOTE:

This product is only intended for use in large-scale fixed installations excluded from the scope of Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS 2).

Section 2: General Information

⚠ CAUTION: FOLLOW PROPER MOUNTING PROCEDURES

The M11D-S package must be mounted with the pump and reservoir upright and vertical. The reservoir fill plug must be removed and replaced, with the breather supplied, before operation.

- 2.1 Numbers in parentheses (), indicate the bubble number (reference number) used on the Bettis Assembly Drawing.
- 2.2 Bettis M11D-S System Assembly Drawing part number 121090.
- 2.3 M11D-S Hydraulic Control System Fluid Requirements: Hydraulic fluids, other than those listed in steps 2.3.1 and 2.3.2, should not be used without prior written approval of Bettis Product Engineering.
 - 2.3.1 Standard and high temperature service (-35°F to +350°F) use Dexron Automatic Transmission Fluid.
 - 2.3.2 Low temperature service (-65°F to +180°F) Use Exxon Unavis J13 Hydraulic Fluid.

⚠ CAUTION: FOLLOW MANUFACTURER'S INSTRUCTIONS

Apply thread sealant per the manufacturer's instructions.

- 2.4 Do not use Teflon tape on threads, use a non-hardening thread sealant on all pipe threads.

Section 3: Actuator Power Operation

- 3.1 Place the M11D-S control valve handle in the Auto position (middle position).

NOTE:

The control valve handle is located in front and below the M11D-S control block (10).

⚠ CAUTION: DO NOT EXCEED OPERATING PRESSURE

Do not exceed the maximum operating pressure rating of the actuator.

- 3.2 Apply an operating media, of the correct pressure, through a control valve to the actuator's power cylinder.

Section 4: Actuator M11D-S Manual Operation

- 4.1 Shut off and exhaust the operating media from both sides of the actuator's power cylinder.
- 4.2 Select actuator rotation desired by placing the control valve handle in the Manual CW or Manual CCW position.
- 4.3 Operate the M11D-S pump until required valve position is reached.

NOTE:

When the actuator is fully stroked against the travel stops, an increased resistance in pumping effort will be noted. Continued operation of the pump simply circulates fluid through a high pressure relief.

Section 5: System Refilling

- 5.1 Use either Refilling Method Number 1 (steps 5.2) or Refilling Method Number 2 (steps 5.3). Method number 1 is the best, most efficient and the recommended method.
- 5.2 REFILLING METHOD NUMBER 1. - Refilling of the M11D-S module and actuator hydraulic cylinder is best accomplished using a pressure pump.

NOTE:

If a pressure pump is not available go to step 5.3 (method number 2) for the manual field service refilling procedure.

- 5.2.1 Actuator position as follows:
 - 5.2.1.1 Pneumatic and Hydraulic HD and T series actuators: Place the actuator in the counter-clockwise (CCW) position and proceed to step 5.2.2.
 - 5.2.1.2 Hydraulic G series actuators: Place the actuator in the counter-clockwise (CCW) position and proceed to step 5.2.2.
 - 5.2.1.3 Pneumatic G series actuators: Place the actuator in the clockwise (CW) position and proceed to step 5.2.2.
- 5.2.2 Shut off and exhaust the operating media from the actuator's power cylinder.
- 5.2.3 Remove the breather (150) from top of M11D-S module reservoir.
- 5.2.4 Attach the pressure pump discharge line to reservoir breather port.
- 5.2.5 Remove two pipe plugs located at each end and on top of the hydraulic cylinder.
- 5.2.6 Place the control valve handle in the "Auto" position.

⚠ WARNING: DO NOT EXCEED OPERATING PRESSURE

Step 5.2.7 is to use a self relieving regulator on the pressure pump and is to be set at a maximum of 3 to 5 psi pressure.

- 5.2.7 Slowly pump hydraulic fluid into the reservoir. As the fluid passes through the M11-S module into the cylinder, air will be displaced at the ports opened in step 5.2.5.
- 5.2.8 Continue to pump until all air has escaped from the cylinder and hydraulic fluid appears at the outboard port.
- 5.2.9 When hydraulic fluid appears install pipe plug, removed in step 5.2.5, into the cylinder's outboard port.
- 5.2.10 Continue to pump until hydraulic fluid appears at the cylinder's inboard port.
- 5.2.11 When hydraulic fluid appears install pipe plug, removed in step 5.2.5, into the cylinder's inboard port.
- 5.2.12 Remove the pressure pump.
- 5.2.13 Adjust reservoir fluid level as follows:
 - 5.2.13.1 Pneumatic and Hydraulic HD and T series actuators: Adjust fluid level to 1-1/2" (40mm) from top of reservoir with actuator in the counter-clockwise (CCW) position.

- 5.2.13.2 Hydraulic G series actuators: Adjust fluid level to 1-1/2" (40mm) from top of reservoir with actuator in the counter-clockwise (CCW) position.
 - 5.2.13.3 Pneumatic G series actuators: Adjust fluid level to 1-1/2" (40mm) from top of reservoir with actuator in the clockwise (CW) position.
 - 5.2.13.4 Re-install breather (150), removed in step 5.2.3, into the top of M11D-S module reservoir.
- 5.3 REFILLING METHOD NUMBER 2. - Refilling the M11D-S Hydraulic Control System during field service often must be done without the use of a pressure pump.
- 5.3.1 Actuator position as follows:
 - 5.3.1.1 Pneumatic and Hydraulic HD and T series actuators: Place the actuator in the counter-clockwise (CCW) position and proceed to step 5.3.2.
 - 5.3.1.2 Hydraulic G series actuators: Place the actuator in the counter-clockwise (CCW) position and proceed to step 5.3.2.
 - 5.3.1.3 Pneumatic G series actuators: Place the actuator in the clockwise (CW) position and proceed to step 5.3.2.
 - 5.3.2 Remove the breather (150) from top of M11D-S module reservoir.
 - 5.3.3 Fill the reservoir approximately three-fourths (3/4) full.
 - 5.3.4 Remove pipe plug located at outboard end and on top of the hydraulic cylinder.
 - 5.3.5 Control valve position as follows:
 - 5.3.5.1 Pneumatic and Hydraulic actuators for HD and T series place the control valve handle in the Manual CW position and proceed to step 5.3.6.
 - 5.3.5.2 Hydraulic G series actuators place the control valve handle in the Manual CW position and proceed to step 5.3.6.
 - 5.3.5.3 Pneumatic G series actuators place control valve handle in the Manual CCW position and proceed to step 5.3.6.

NOTE:

During the fill procedure, it is important that the lowest level be not less than approximately one-fourth (1/4) of the reservoir volume at any time.

- 5.3.6 Operate hand pump slowly. Keep pump handle up for about 4 to 5 seconds before each pressure stroke (not mandatory). This allows time for the pump cylinder to fill in order that full displacement of the pump is utilized.
- 5.3.7 Continue to operate hand pump until all air has escaped from the open port per step 5.3.4.
- 5.3.8 When fluid appears install pipe plug, removed in step 5.3.4, into the cylinder's outboard port.
- 5.3.9 Remove pipe plug located at inboard end and on top of the hydraulic cylinder.
- 5.3.10 Control valve position as follows:
 - 5.3.10.1 Pneumatic and Hydraulic actuators for HD and T series place the control valve handle in the Manual CCW position and proceed to step 5.3.11.
 - 5.3.10.2 Hydraulic G series actuators place the control valve handle in the Manual CCW position and proceed to step 5.3.11.
 - 5.3.10.3 Pneumatic G series actuators place control valve handle in the Manual CW position and proceed to step 5.3.11.

NOTE:

During the fill procedure, it is important that the lowest level be not less than approximately one-fourth (1/4) of the reservoir volume at any time.

- 5.3.11 Operate hand pump slowly. Keep handle up for about 4 to 5 seconds before each pressure stroke (not mandatory). This allows time for the pump cylinder to fill in order that full displacement of the pup is utilized.
- 5.3.12 Continue to operate hand pump until all air has escaped from the open port.
- 5.3.13 When hydraulic fluid appears install pipe plug, removed in step 5.3.9, into the cylinders' inboard port.
- 5.3.14 Adjust reservoir fluid level as follows:
 - 5.3.14.1 Pneumatic and Hydraulic HD and T series actuators: Adjust fluid level to 1-1/2" (40mm) from top of reservoir with actuator in the counter-clockwise (CCW) position.
 - 5.3.14.2 Hydraulic G series actuators: Adjust fluid level to 1-1/2" (40mm) from top of reservoir with actuator in the counter-clockwise (CCW) position.
 - 5.3.14.3 Pneumatic G series actuators: Adjust fluid level to 1-1/2" (40mm) from top of reservoir with actuator in the clockwise (CW) position.
- 5.4 Additional M11D-S Instructions These steps are to be performed to insure air is removed from the system and to test the operation of M11D-S hydraulic control system.
 - 5.4.1 Control valve position as follows:
 - 5.4.1.1 Pneumatic and Hydraulic actuators for HD and T series place the control valve handle in the Manual CW position and proceed to step 5.4.2.
 - 5.4.1.2 Hydraulic G series actuators place the control valve handle in the Manual CW position and proceed to step 5.4.2.
 - 5.4.1.3 Pneumatic G series actuators place control valve handle in the Manual CCW position and proceed to step 5.4.3.
 - 5.4.2 Operate M11D-S pump handle and the actuator should move clockwise (CW). Skip step 5.4.3 and continue at step 5.3.4.
 - 5.4.3 Operate M11D-S pump handle and the actuator should move counter-clockwise (CCW).

⚠ CAUTION: ESCAPING FLUIDS ARE UNDER PRESSURE

Before pipe plug removal in step 5.4.4 have the ability to capture any fluid that might flow from the pipe plug hole, i.e. pan, rags, etc. Fluid will be under pressure.

- 5.4.4 Remove outboard pipe plug to release any trapped air from system and then replace the pipe plug.
- 5.4.5 Control valve position as follows:
 - 5.4.5.1 Pneumatic and Hydraulic actuators for HD and T series place the control valve handle in the Manual CCW position and proceed to step 5.4.6.
 - 5.4.5.2 Hydraulic G series actuators place the control valve handle in the Manual CCW position and proceed to step 5.4.6.
 - 5.4.5.3 Pneumatic G series actuators place control valve handle in the Manual CW position and proceed to step 5.4.7.

- 5.4.6 Operate M11D-S pump handle and the actuator should move counter-clockwise (CCW). Skip step 5.4.7 and continue at step 5.4.8
- 5.4.7 Operate M11D-S pump handle and the actuator should move clockwise (CW).

⚠ CAUTION: ESCAPING FLUIDS ARE UNDER PRESSURE

Before pipe plug removal in step 5.4.8 have the ability to capture any fluid that might flow from the pipe plug hole, i.e. pan, rags, ect. Fluid will be under pressure.

- 5.4.8 Remove outboard pipe plug to release any trapped air from system and then replace the pipe plug.
- 5.4.9 Using M11D-S Hydraulic Module manually stroke the actuator full 90° degrees clockwise (CW) and then manually stroke the actuator full 90° degrees counterclockwise (CCW).
- 5.4.10 Remove the breather (150) from top of M11D-S module reservoir.
- 5.4.11 Add fluid to reservoir so that level is within approximately 1 inch through 1-1/2 inches of fluid from the top of the reservoir.
- 5.4.12 Re-install breather (150), removed in step 5.4.8, into the top of M11D-S module reservoir.
- 5.4.13 Connect power supply lines back to the actuator control system or power cylinder and cycle the actuator using available power media.


Section 6: Document Revision

Table 1. Revision Overview

ECN	DATE	REV		BY *	DATE
Released	January, 1998	A	COMPILED	Bill Cornelius	16 January 1998
			CHECKED	Gary Burrows	16 January 1998
			APPROVED	Tom Jeansonne	16 January 1998

* Signatures on file Bettis Actuator & Controls, Waller, Texas

A.2 Part No. 121090, Assembly Dwg M11D-S, Sheet 2 of 3



HDX, T SERIES (DA)

ITEM LTR	PART NAME	MODEL SP3A PART NDI	QUANT
A	BODY ASSEMBLY	SP1A-1	1
B	PLUNGER	P3-2	1
C	PUMP BARREL	P3-3	1
D	PUMP PISTON PACKING	P3-4	1
E	PUMP PISTON WIPER	P3-6	1
F	PUMP BARREL *TRING	P1-20	1
G	PIN (INCL. RINGS)	CP13-10RP	3
H	LEVER HANDLE	CP13-23	1
J	PUMP SOCKET	CP13-9	1
K	PUMP VALVE (COMPLETED)	PL-12RP	1
L	PUMP LINK	CP13-12	1

G SERIES (DA)

ITEM LTR	PART NAME	MODEL SP3A PART NDI	QUANT
A	BODY ASSEMBLY	SP1A-1	1
B	PLUNGER	121055-020	1
C	PUMP BARREL	121054	1
D	PUMP PISTON PACKING	121056	1
E	PUMP PISTON WIPER	121057	1
F	PUMP BARREL *TRING	P1-20	1
G	PIN (INCL. RINGS)	CP13-10RP	3
H	LEVER HANDLE	CP13-23	1
J	PUMP SOCKET	CP13-9	1
K	PUMP VALVE (COMPLETED)	PL-12RP	1
L	PUMP LINK	CP13-12	1

PART NDI: 121090 REV: E SHT 2

World Area Configuration Centers (WACC) offer sales support, service, inventory and commissioning to our global customers. Choose the WACC or sales office nearest you:

NORTH & SOUTH AMERICA

19200 Northwest Freeway
Houston TX 77065
USA
T +1 281 477 4100

Av. Hollingsworth
325 Iporanga Sorocaba
SP 18087-105
Brazil
T +55 15 3413 8888

ASIA PACIFIC

No. 9 Gul Road
#01-02 Singapore 629361
T +65 6777 8211

No. 1 Lai Yuan Road
Wuqing Development Area
Tianjin 301700
P. R. China
T +86 22 8212 3300

MIDDLE EAST & AFRICA

P. O. Box 17033
Jebel Ali Free Zone
Dubai
T +971 4 811 8100

P. O. Box 10305
Jubail 31961
Saudi Arabia
T +966 3 340 8650

24 Angus Crescent
Longmeadow Business Estate East
P.O. Box 6908 Greenstone
1616 Modderfontein Extension 5
South Africa
T +27 11 451 3700

EUROPE

Holland Fisor 6
Székesfehérvár 8000
Hungary
T +36 22 53 09 50

Strada Biffi 165
29017 Fiorenzuola d'Arda (PC)
Italy
T +39 0523 944 411

For complete list of sales and manufacturing sites, please visit www.emerson.com/actuationtechnologieslocations or contact us at info.actuationtechnologies@emerson.com

www.emerson.com/bettis

©2018 Emerson. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Bettis™ is a mark of one of the Emerson family of companies. All other marks are property of their respective owners.

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

BETTIS™

